

EAGLE COPTERS MAINTENANCE LTD.

823 McTavish Road NE Calgary, AB, T2E 7G9 Canada

Phone: 1.403.250.7370 Toll Free: 1.800.564.6469

e-mail: engineering@eaglecopters.com http://www.eaglecopters.com

Technical Bulletin Torque Indicator Replacement

B212

TBN-212-003

Revision A

March 24, 2023

Prepared:	Adam Stenger
	A. Stenger
Reviewed:	Matter
	M. Peters
Released:	Matte
	M. Peters

THIS DOCUMENT IS UNCONTROLLED UNLESS OPENED DIRECTLY FROM ECML'S CONTROLLED REPOSITORY

Revision Record

Rev	Date	Description of Revision	
А	See Cover Page	Initial Release.	

TABLE OF CONTENTS

1.	Introduction	4
1.1.	Approval	4
1.2.	Purpose	4
1.3.	Effectivity	4
1.4.	Compliance	4
1.5.	Description	4
2.	Installation Data	5
2.1.	Parts Lists	5
2.2.	Weight and Balance	5
2.3.	Electrical Loads	5
3.	Installation and Calibration Procedure	6
3.1.	65100-068 Torque Indicator Removal	.6
3.2.	65100-057 Torque Indicator Installation	6
4.	Operational Check	8
5.	Aircraft Record Set Update and Eagle Notification	9

LIST OF TABLES

Table 1 – Removed Parts	5
Table 2 – Installed Parts	5

Technical Bulletin Torque Indicator Replacement B212

1. Introduction

1.1. Approval

This Technical Bulletin is approved data in accordance with the following STC:

TCCA STC: SH07-28

FAA STC: SR02831NY

1.2. Purpose

The Technical Bulletin provides procedures for the replacement of the Diamond J P/N 65100-068 Torque Meter with the 65100-057 Torque Meter.

1.3. Effectivity

STC SH07-28 is a pre-requisite to this change.



1.4. Compliance

Optional

1.5. Description

This Technical Bulletin provides the data required for the replacement of the Diamond J P/N 65100-068 torque meter with the 65100-057 torque meter. The -057 torque meter includes a dampened needle response to reduce momentary spikes as well as changes to the thresholds for the indicator's recording feature. The -057 torque meter will continue to indicate exceedances between 100.1% and 104%, but will not record or playback those exceedances. Recording for exceedances of 104.1% or greater will continue to be recorded and played back in the same manner as the -068 torque meter.

2. Installation Data

2.1. Parts Lists

Item	Qty	Part Number	Description
1	2	65100-068	Diamond J Torque Indicator

Table 1 – Removed Parts

Item	Qty	Part Number	Description
1	2	65100-057	Diamond J Torque Indicator

Table 2 – Installed Parts

2.2. Weight and Balance

There is no change to aircraft weight and balance as a result of this change.

2.3. Electrical Loads

There is no change to aircraft electrical loads as a result of this change.

3. Installation and Calibration Procedure

3.1. 65100-068 Torque Indicator Removal

- 1. Ensure that the "TORQUE IND PILOT" or "TORQUE IND COPLT" circuit breaker is pulled to suit the position of the indicator being replaced.
- 2. Loosen the indicator clamp screw adjacent to the indicator on the instrument panel. If there is more than one screw adjacent to the indicator, loosen the larger screw.
- 3. Slide the indicator out of the indicator panel.
- 4. Verify the connector labeling corresponds to the indicator.
- 5. Disconnect the connector from the back of the indicator.

3.2. 65100-057 Torque Indicator Installation

- 1. Ensure that the "TORQUE IND PILOT" or "TORQUE IND COPLT" circuit breaker is pulled to suit the position of the indicator being replaced.
- 2. Check that the connector is through the proper indicator hole on the instrument panel.
- 3. Verify the connector labeling corresponds to the indicator.
- **NOTE:** The torque indicator must be aligned to the engine torque pressure setting on the engine data plate.
- 4. Connect the calibration stick P/N 10012-033 in line between the indicator and the corresponding electrical connector for the torque indicator.
- 5. Attach dead weight pressure tester to the torque transmitter. Set the pressure on the dead weight tester to 0.2 x P (Calibration point 1)

$$P = \left(\frac{ENG \ Data \ Plate}{47.5}\right) x \ 55.7$$

- 6. Close the circuit breaker opened in Section 3.2, Step 1. The indicator will display "CA" for 5 seconds, then will display the current torque pressure for 10 seconds, then display "CA" for another 5 seconds, then display "CA1", indicating that calibration point 1 has been stored.
- 7. Open the circuit breaker again.
- 8. Set the pressure on the dead weight tester to 0.95 x P (Calibration point 2).

$$P = \left(\frac{Eng \ Data \ Plate}{47.5}\right) x \ 55.7$$

- 9. Close the circuit breaker. The indicator will display "CA" for 5 seconds, then will display the current torque pressure for 10 seconds, then display "CA" for another 5 seconds, then display "CA2", indicating that calibration point 2 has been stored.
- 10. Open the circuit breaker again.
- 11. Remove calibration stick and reconnect the corresponding electrical connector.
- 12. Slide the indicator into the hole and align the indicator so that the display is properly oriented.

- 13. Tighten the indicator clamp screw adjacent to the indicator on the instrument panel. If there is more than one screw adjacent to the indicator, tighten the larger screw.
- 14. Repeat Sections 3.1 & 3.2 for the remaining torque indicator.
- **NOTE:** Both torque indicators must be replaced together and the pilot's and copilot's torque indicator P/Ns must be the same.

4. Operational Check

- 1. Ensure that the "TORQUE IND PILOT" or "TORQUE IND COPLT" circuit breaker is closed.
- 2. Verify the calibration by first setting the dead weight tester to the value calculated in Section 3.2, Step 5 and verify the indicator reads $20 \pm 0.2\%$. Then set the dead weight tester to the value calculated in Section 3.2, Step 8 and verify the indicator reads $95 \pm 0.2\%$.
- 3. Repeat Steps 1 & 2 for the remaining torque indicator.

5. Aircraft Record Set Update and Eagle Notification

- 1. Make an entry in the aircraft record set that TBN-212-003 has been incorporated.
- 2. Update the aircraft's Weight and Balance and Electrical Loads records with the values in Section 2 as required.
- 3. Notify Eagle Copters that TBN-212-003 has been incorporated by emailing the below information to <u>customersupport@eaglecopters.com</u>:

Aircraft Serial Number

Aircraft Owner

Date Incorporated