EAGLE COPTERS LTD. · CALGARY, CANADA

EPCS
EAGLE PART & COMPONENT SOLUTIONS

BELL TEXTRON · BELL 204

# BELL 204 PARTS AVAILABLE NOW



Rotor grips, crosshead, transmission components and 130+ part numbers in stock.

| PART DESCRIPTION | PART NUMBER |
|---|---|
| Grip Assy | 205-011-711-101 |
| Crosshead Assy | 204-011-711-001 |
| Sump Input Quill Assy | 204-040-206-011 |
| Pinion | 204-040-400-009 |

| PART DESCRIPTION | PART NUMBER |
|---|---|
| Hook Assy | 17149-2 |
| Oil Cooler | 8532400 |
| Fuel Cell | 204-062-611-005 |
| Tripod Assy | 204-060-157-001 |

**For Availability & Pricing, please contact** partsales@eaglecopters.com

EAGLE COPTERS LTD. · CALGARY, CANADA

EPCS
EAGLE PART & COMPONENT SOLUTIONS

# BELL 204 PARTS LIST

163 line items · 133 part numbers. Offered subject to prior sale.

## FEATURED COMPONENTS

| PART DESCRIPTION | PART NUMBER | CATEGORY |
|---|---|---|
| Grip Assy | 205-011-711-101 | Rotor |
| Crosshead Assy | 204-011-711-001 | Rotor |
| Sump Input Quill Assy | 204-040-206-011 | Drive train |
| Pinion | 204-040-400-009 | Drive train |
| Sleeve Assy | 204-040-425-001 | Drive train |
| Case / Case Assy | 204-040-418-015 / 204-040-513-001 | Drive train |
| Gear | 204-040-103-009 | Drive train |
| Oil Cooler | 8532400 | Oil system |
| Hook Assy | 17149-2 | Utility |
| Tripod Assy | 204-060-157-001 | Engine install |
| Screen Assembly | 204-060-210-103 | Engine install |
| Fuel Cell | 204-062-611-005 | Fuel system |
| Fuel Quantity Indicator | 204-062-610-003 | Fuel system |
| Elevators – L/H & R/H (ECM STC) | 39705-01 / 39705-02 | Airframe |
| Elevator | 204-030-858-054 | Airframe |
| Panel Assy | 204-030-772-039 / 204-031-178-005 | Airframe |
| Floor Assy | 204-030-173-038 | Airframe |
| Instrument Panel | EA20469-15-204 | Airframe |

**For Availability & Pricing, please contact** partsales@eaglecopters.com

## FULL PARTS LIST

| PART NUMBER | PART DESCRIPTION |
|---|---|
| 204-030-772-039 | PANEL ASSY |
| 204-030-291-016 | CAP ASSY |
| 204-031-178-005 | PANEL ASSY |
| 205-011-711-101 | GRIP ASSY |
| 205-011-711-101 | GRIP ASSY |
| 204-031-277-005 | PANEL ASSY |
| 204-030-062-003 | PANEL ASSY |
| 204-032-841-007 | PANEL |
| 204-060-210-103 | SCREEN ASSEMBLY |
| 17149-2 | HOOK ASSY |
| 204-060-157-001 | TRIPOD ASSY |
| 204-040-345-007 | BEARING |
| 204-040-425-001 | SLEEVE ASSY |
| 204-040-400-009 | PINION |
| 8532400 | Oil Cooler |
| 204-031-467-007A | HINGE HALF ASSY |
| 204-011-711-001 | CROSSHEAD ASSY |
| 204-032-730-001 | SPACER |
| 204-032-730-001 | SPACER |
| 204-001-793-005 | SUPPORT ASSY |
| 204-070-711-019 | Lifter |
| 204-001-018-027 | TUBE ASSY |
| 204-032-730-001 | SPACER |
| 204-076-209-001 | TUBE ASSEMBLY |
| 204-076-052-009 | CYLINDER |
| 204-076-052-009 | CYLINDER |
| 204-030-173-038 | FLOOR ASSY |
| 204-001-027-019 | TUBE ASSY |
| 204-061-675-001 | Tube |
| 204-030-736-001 | Cable Assy |
| 204-031-919-038 | CLIP |
| 204-062-610-003 | FUEL QUANTITY IND. |
| 204-040-406-001 | BEARING |
| 204-060-808-005 | Bushing |

| PART NUMBER | PART DESCRIPTION |
|---|---|
| 204-030-772-025 | Bumper |
| 204-030-196-015 | CONTROL TUBE BOOT |
| 204-040-103-009 | GEAR |
| 204-030-772-025 | Bumper |
| 204-040-631-001 | BOLT |
| 204-001-821-001 | SPACER |
| 204-040-347-001 | PLATE |
| 204-040-427-003FM | NUT |
| 204-040-631-001 | BOLT |
| 204-040-186-001 | NUT |
| 204-061-635-001 | CONNECTOR |
| 204-040-186-001 | NUT |
| 204-040-170-005 | SPACER |
| 204-040-170-005 | SPACER |
| 204-040-170-005 | SPACER |
| 204-001-858-001 | COVER |
| 204-060-829-003 | CLAMP |
| 204-040-170-005 | SPACER |
| 204-030-169-063 | PANEL ASSY |
| 204-032-750-021S | TRACK - UPR |
| 204-032-750-022S | TRACK |
| 204-032-750-022S | TRACK |
| 204-060-944-001 | FITTING |
| 204-032-750-020 | TRACK |
| 204-060-631-025 | SUMP |
| 204-062-520-003 | VALVE |
| 204-001-961-001 | TUBE ASSEMBLY |
| 204-030-813-033 | AFT T/B DRIVESHAFT COVER |
| 204-070-099-013 | SEAT TUBE ASSY |
| 204-031-467-007A | HINGE HALF ASSY |
| 204-040-407-003 | BEARING |
| 204-040-406-001 | BEARING |
| 204-012-105-005 | STATIC STOP |
| 204-032-750-019 | TRACK |
| 204-031-919-077 | Web |

| PART NUMBER | PART DESCRIPTION |
|---|---|
| 204-001-027-023 | TUBE, ASSY OF |
| 204-001-072-003 | TUBE |
| 204-001-072-009 | TUBE ASSEMBLY |
| 204-001-073-003 | CONTROL TUBE |
| 204-001-373-001 | BELLCRANK ASSY |
| 204-001-373-001 | BELLCRANK ASSY |
| 204-001-724-005 | LINK ASSY |
| 204-001-784-001 | LINK ASSY |
| 204-001-800-001 | BELLCRANK ASSY |
| 204-001-844-001 | BELLCRANK |
| 204-001-858-001 | COVER |
| 204-001-937-005 | HORN ASSY |
| 204-001-964-003 | BUSHING |
| 204-010-712-005 | Ring |
| 204-011-177-001 | SHIM |
| 204-011-708-003 | WASHER |
| 204-011-721-001 | RING |
| 204-030-071-015 | PANEL ASSY |
| 204-030-191-025 | PANEL ASSY |
| 204-030-191-026 | PANEL ASSY |
| 204-030-191-026 | PANEL ASSY |
| 204-030-191-026 | PANEL ASSY |
| 204-030-194-003 | Track |
| 204-030-448-009 | FITTING |
| 204-030-819-021 | FITTING ASSY |
| 204-030-819-021 | FITTING ASSY |
| 204-030-819-021 | FITTING ASSY |
| 204-030-819-021 | FITTING ASSY |
| 204-030-819-023 | Fitting |
| 204-030-819-023 | Fitting |
| 204-030-858-054 | ELEVATOR |
| 204-031-105-009 | FITTING |
| 204-031-146-002 | SUPPORT |
| 204-031-147-002 | SUPPORT ASSY |
| 204-031-197-073 | COVER |

| PART NUMBER | PART DESCRIPTION |
|---|---|
| 204-031-197-095 | DECK ASSY |
| 204-031-203-007 | PANEL ASSY |
| 204-031-277-005 | PANEL ASSY |
| 204-031-286-003 | PANEL ASSY |
| 204-031-837-007 | Hinge |
| 204-032-731-001 | SPACER |
| 204-032-806-075A | LONGERON |
| 204-032-808-003 | PANEL ASSEMBLY |
| 204-032-820-002 | FITTING |
| 204-040-104-017 | PINION |
| 204-040-159-003 | PLATE |
| 204-040-186-001 | NUT |
| 204-040-186-001 | NUT |
| 204-040-206-011 | QUILL ASSY SUMP INPUT |
| 204-040-345-007 | BEARING |
| 204-040-418-015 | CASE |
| 204-040-418-015 | CASE |
| 204-040-502-011 | CAP ASSY |
| 204-040-513-001 | CASE ASSY |
| 204-040-716-001 | Coupling |
| 204-060-149-001 | TUBE ASSY |
| 204-060-180-001 | TUBE ASSEMBLY |
| 204-060-459-001 | DUCT ASSY. |
| 204-060-459-001 | DUCT ASSY. |
| 204-060-579-001 | TUBE ASSY |
| 204-060-719-043 | Tube Assy. |
| 204-060-736-001 | END ASSEMBLY |
| 204-060-747-001 | CLEVIS |
| 204-060-819-003 | Beam |
| 204-060-848-001 | INSERT |
| 204-060-855-009 | Tube Assy. |
| 204-060-934-001 | Fitting |
| 204-060-944-001 | FITTING |
| 204-060-979-001 | TUBE ASSY |
| 204-060-980-001 | TUBE ASSY |

| PART NUMBER | PART DESCRIPTION |
|---|---|
| 204-060-981-001 | Tube Assy. |
| 204-060-983-001 | TUBE ASSY |
| 204-060-983-001 | TUBE ASSY |
| 204-060-984-001 | TUBE ASSY |
| 204-061-648-001 | TUBE |
| 204-061-680-001 | Tube Assy. |
| 204-061-826-001 | FITTING |
| 204-062-611-005 | S/S FUEL CELL |
| 204-062-622-001 | FITTING |
| 204-062-649-001 | FITTING |
| 204-062-836-001 | FITTING |
| 204-062-880-001 | Tube Assy. |
| 204-070-476-001 | BRACKET ASSEMBLY |
| 204-070-710-005 | FITTING |
| 204-070-992-001 | STOP |
| 204-070-992-001 | STOP |
| 204-072-162-001 | BRACKET ASSY. |
| 204-072-170-003 | LEG ASSY, FRONT |
| 204-075-363-001 | RELAY ASSY |
| 204-076-207-001 | TUBE ASSEMBLY |
| 204-076-267-005 | TUBE ASSY |
| 39705-01 | L/H ELEVATOR |
| 39705-02 | ELEVATOR ECM STC RIGHT HAND 204 |
| EA20469-15-204 | Instrument Panel, 204 |