EAGLE

EAGLE COPTERS LTD. · CALGARY, CANADA

EPCS

EAGLE PART & COMPONENT SOLUTIONS

BELL TEXTRON · BELL 212

BELL 212 PARTS AVAILABLE NOW



Engine cowlings, firewalls, fairings and 80+ part numbers in stock.

PART DESCRIPTION	PART NUMBER
Radome	212-755-051
Fairing Assy, Transmission	212-060-801-001
Cowl Assy, Twin Gearbox	212-061-808-004
Cowling Instl	212-060-800-101

PART DESCRIPTION	PART NUMBER
Oil Cooler Assy	85388100
Radar Mount	212-576-020
Firewall Assy, Aft	212-061-902-205
Ejector Assy, Exhaust	212-061-216-102

For Availability & Pricing, please contact partsales@eaglecopters.com

EAGLE COPTERS LTD. · CALGARY, CANADA

EPCS
EAGLE PART & COMPONENT SOLUTIONS

BELL 212 PARTS LIST

147 line items · 89 part numbers. Offered subject to prior sale.

FEATURED COMPONENTS

PART DESCRIPTION	PART NUMBER	CATEGORY
Radome	212-755-051	Airframe
Radar Mount	212-576-020	Airframe
Oil Cooler Assy	85388100	Oil system
Boot, Oil Cooler Blower	209-062-519-001	Oil system
Cowl Assy, Oil Cooler Support	212-061-811-009 / 212-061-811-013	Cowling
Cowl Assy, Twin Gearbox – Top LH / RH	212-061-808-003 / 212-061-808-004	Cowling
Cowl Assy, Twin Gearbox – Side LH / RH	212-061-812-103 / 212-061-812-104	Cowling
Cowling Instl	212-060-800-101	Cowling
Cowling Assy, Engine, Lower	212-060-805-015 / 212-060-805-116	Cowling
Fairing Assy, Transmission	212-060-801-001	Fairing
Fairing Assy, Engine Air Inlet, RH	212-060-802-164	Fairing
Firewall Assy, Aft	212-061-902-205 / 212-061-902-235	Firewall
Firewall Assy, LH / RH	212-061-902-223 / 212-061-902-224	Firewall
Air Management System Instl, LH / RH	212-061-200-101 / 212-061-200-102	Engine install
Ejector Assy, Exhaust, LH / RH	212-061-216-101 / 212-061-216-102	Engine install
Baffle Assy, Induction, LH / RH	212-061-207-293 / 212-061-207-295	Engine install
Duct Assy, Inlet	212-070-435-003	Engine install
Valve Assy	212-060-203-001	Engine install

For Availability & Pricing, please contact partsales@eaglecopters.com

FULL PARTS LIST

PART NUMBER	PART DESCRIPTION
212-060-802-164	FAIRING ASSY, ENGINE AIR INLET, RH
212-061-813-013	FAIRING ASSY, OIL COOLER
212-060-801-001	FAIRING ASSY, TRANSMISSION
212-755-051	RADOME
212-060-803-103	COWL ASSY TOP LH
212-060-803-165	COWL ASSY TOP
212-061-811-009	COWL ASSY, OIL COOLER, SUPPORT
212-061-903-199	WEB ASSY, UPPER
212-061-200-101	AIR MANAGEMENT, SYSTEM INSTL, LH
212-061-902-114	SEAL ASSY, RH
212-061-902-113	SEAL ASSY, LH
212-061-901-236	FIREWALL ASSY, RH
212-061-903-185	COVER ASSY
212-060-901-181	FIREWALL ASSY, LH
212-060-901-183	FIREWALL ASSY, RH
212-061-903-009	COVER ASSY
212-061-092-201	FIREWALL ASSY
212-060-900-303	FIREWALL ASSY
212-061-808-004	COWL ASSY, TWIN GEARBOX, TOP RH
212-061-811-081	FRAME
212-061-511-015	COWLING ASSY, ENGINE, LOWER, LH
212-060-817-103	PILLAR ASSY RH
212-060-817-104	PILLAR ASSY RH
212-061-807-011	C BOX PANEL
212-061-812-103	COWL ASSY, TWIN GEARBOX, LH SIDE
212-061-812-104	COWL ASSY, TWIN GEARBOX, RH SIDE
212-061-207-035	SCREEN ASSY
212-060-805-015	COWLING ASSY, ENGINE, LOWER, LH
212-061-216-101	EJECTOR ASSY, EXHAUST, LH
212-060-804-073	SKIN LH
212-060-804-074	SKIN RH
212-061-814-137	DOUBLER ASSY
212-061-814-138	DOUBLER ASSY
212-060-802-163	FAIRING ASSY, ENGINE AIR OUTLET, LH

PART NUMBER	PART DESCRIPTION
212-060-803-165	COWL ASSY
212-060-805-005	COWL ASSY LH
212-060-805-116	COWLING ASSY, ENGINE, LOWER, RH
212-063-801-001	FAIRING ASSY, TRANSMISSION
212-755-051	RADOME
212-060-800-101	COWLING INSTL
212-061-200-101	AIR MANAGEMENT SYSTEM INSTL, LH
212-060-901-215	FIREWALL ASSY, LH
212-061-902-113	SEAL ASSY, LH
212-061-902-053	FIREWALL DOUBLER
212-061-902-053	FIREWALL DOUBLER
212-061-902-224	FIREWALL ASSY, RH
212-061-902-223	FIREWALL ASSY, LH
212-061-200-102	AIR MANAGEMENT SYSTEM INSTL, RH
212-060-901-217	FIREWALL ASSY, RH
212-061-903-009	COVER ASSY, LOWER
212-061-902-201	FIREWALL ASSY, AFT (S/N 35038 THRU 35065)
212-060-900-299	FIREWALL ASSY, FW
212-060-203-001	VALVE ASSY
212-060-203-001	VALVE ASSY
212-061-903-165	FIREWALL ASSY
209-062-519-001	BOOT, OIL COOLER BLOWER
209-062-519-001	BOOT, OIL COOLER BLOWER
212-061-811-129	SKIN
212-060-204-001	DUCT ASSY, LH
212-060-204-002	DUCT ASSY, RH
212-061-814-142	FAIRING ASSY, RH
212-061-814-142	FAIRING ASSY, RH
212-060-817-008	PILLAR ASSY, RH
212-060-817-008	PILLAR ASSY, RH
212-061-812-112	DOOR ASSY RH
212-061-812-067	FRAME, LH
212-061-811-013	COWL ASSY, OIL COOLER, SUPPORT
212-061-811-043	SKIN,LH
212-061-903-177	WEB ASSY, UPPER

PART NUMBER	PART DESCRIPTION
212-060-803-103	COWL ASSY TOP
212-061-216-102	EJECTOR ASSY, EXHAUST, RH
212-061-216-101	EJECTOR ASSY, EXHAUST, LH
212-061-808-004	COWL ASSY, TWIN GEARBOX, TOP RH
212-061-808-003	COWL ASSY, TWIN GEARBOX, TOP LH
212-755-051	RADOME ASSY
212-060-801-001	FAIRING ASSY, TRANSMISSION
212-060-803-165	COWL ASSY TOP
212-060-800-101	COWLING INSTL
212-061-200-102	AIR MANAGEMENT SYSTEM INSTL, RH
212-060-805-009	COWL ASSY, ENGINE, LOWER, LH
212-061-811-013	COWL ASSY, OIL COOLER, SUPPORT
212-060-805-115	COWLING
212-061-210-003	DUCT ASSY, LH
212-061-903-007	WEB ASSY, UPPER
212-060-900-303	FIREWALL ASSY
212-061-903-009	COVER ASSY, LOWER
212-060-900-303	FIREWALL ASSY
212-061-902-235	FIREWALL ASSY, AFT
212-061-903-185	COVER ASSY
212-060-901-217	COVER ASSY, LOWER
212-060-203-001	VALVE ASSY
212-060-203-001	VALVE ASSY
212-061-207-293	BAFFLE ASSY, INDUCTION, LH
212-061-207-295	BAFFLE ASSY, INDUCTION, RH
212-061-514-104	FIREWALL COVER
212-060-800-101	COWLING INSTL
212-061-812-103	COWL ASSY, TWIN GEARBOX, LH SIDE
212-061-812-104	COWL ASSY, TWIN GEARBOX, RH SIDE
212-060-817-106	FRAME
212-060-817-007	PILLAR ASSY, LH
212-061-811-081	FRAME
212-061-814-141	FAIRING ASSY, LH
212-061-811-044	SKIN RH
212-060-804-073	SKIN RH

PART NUMBER	PART DESCRIPTION
212-060-804-074	SKIN LH
212-061-204-102	EJECTOR ASSY, EXHAUST, RH
212-061-204-102	EJECTOR ASSY, EXHAUST, RH
212-060-204-002	DUCT ASSY, RH
212-060-204-002	DUCT ASSY, RH
212-061-207-035	SCREEN ASSY
212-060-802-097	FAIRING ASSY, AIR INLET, LH
212-061-813-011	FAIRING ASSY
212-060-803-163	COWL ASSY
212-060-803-163	COWL ASSY
212-060-808-003	COWLING ASSY
212-755-051	RADOME ASSY
212-061-808-004	COWL ASSY, TWIN GEARBOX, TOP RH
212-070-435-003	DUCT ASSY, INLET
212-061-807-011	C BOX PANEL
212-061-903-185	COVER ASSY
85388100	OIL COOLER ASSY
212-576-020	RADAR MOUNT
212-060-900-289	FIREWALL ASSY
212-060-805-110	COWL ASSY, RH
212-060-808-109	COWL ASSY
212-061-811-081	FRAME
212-061-812-104	COWL ASSY, TWIN GEARBOX, RH SIDE
212-060-817-105	FRAME ASSY, LH
212-061-902-205	FIREWALL ASSY, AFT
212-061-903-009	COVER ASSY
212-061-902-223	FIREWALL ASSY, LH
212-061-902-224	FIREWALL ASSY, RH
212-060-901-217	FIREWALL ASSY, RH
212-060-901-215	FIREWALL ASSY, LH
212-061-814-103	FAIRING ASSY, LH
212-060-800-101	COWLING INSTL
212-061-811-010	COWL ASSY, OIL COOLER, SUPPORT
212-061-811-009	COWL ASSY, OIL COOLER, SUPPORT
212-060-203-001	VALVE ASSY

PART NUMBER	PART DESCRIPTION
212-060-204-002	DUCT ASSY, RH
209-062-519-001	BOOT, OIL COOLER BLOWER
209-062-519-001	BOOT, OIL COOLER BLOWER
209-060-203-001	VALVE ASSY
212-061-903-199	WEB ASSY, UPPER
212-061-216-102	EJECTOR ASSY, EXHAUST, RH
212-061-216-102	EJECTOR ASSY, EXHAUST, RH
212-061-207-035	SCREEN ASSY