

BELL 412EP COMPONENT COVERAGE

MAIN ROTOR HUB

Yoke Assembly
Spindle Assembly
Pitch Horn Assembly
Blade Retention Bolt
Cap Retention
Upper Cone
Drive Pin
Upper Cone Seat

Splined Plate Assembly Lower Cone

Lower Cone Seat

Damper Bridge Upper/Lower

Fitting

MAIN ROTOR CONTROLS

Rephasing Lever Assembly
Drive Link Assembly
Swashplate Outer Ring
Swashplate Link Rod End Bearing
Swashplate Support Assembly
Gimbal Ring to Swashplate Support
Swashplate
Collective Lever
Hub and Sleeve Assembly
Main Rotor Pitch Links
Gimbal Ring to Swashplate Inner Ring
Gimbal Ring Assembly
Collective Sleeve
Collective Lever Assembly

TAIL ROTOR INSTALLATION

Tail Rotor Hub Assembly Blade Assembly Yoke Assembly

FIRE EXTINGUISHER

Engine Fire Extinguisher Container Fire Extinguisher Squib

FLOATS

Squib Cartridges Cylinder Assembly

MAIN ROTOR BLADE**

POWER PLANT

Power Section*
Fuel Pump
Automatic Fuel Control Unit
Manual Fuel Control Unit
Oil to Fuel Heater
Starter Generator
Combining Gearbox
Torque Control Unit
Governor

POWER TRAIN

Rotor Brake Quill
Main Driveshaft Assembly
Transmission
Intermediate Gearbox
Tail Rotor Gearbox Assembly
Tail Rotor Driveshaft Hangars
Tail Rotor Driveshaft Coupling
Mast Assembly

HYDRAULIC

Flight Control Hydraulic Cyclinders (Cyclic and Collective)

^{*} All internal life-limited Power Section components are covered.

^{**} All on condition repairs for cosmetics and erosion shall be for the account of the Lessee, unless otherwise noted on the pre-lease inspection, for the term of the lease. Repairs required for return to service or resulting in blade replacement will be invoiced to the Lessee on a prorata basis.