



IPC-D212-725 (01)

Eagle Copters Ltd.
823 McTavish Road NE
Calgary, AB, T2E 7G9
Canada

Tel: 1 403 250 7370

<http://www.eaglecopters.com>



ILLUSTRATED PARTS CATALOG

IPC-D212-725

Single Engine Conversion

BELL 212 MODELS

Prepared By: Adam Stenger
A. Stenger

Reviewed By: M. Peters
M. Peters

Released By: M. Peters
M. Peters

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **3**

Date: 23.09.01

CHAPTER 01 – INTRODUCTION (01-00-00)

REVISION RECORD

Revision No.	Issue Date	Description	Date Inserted	Inserted By
0	11.06.06	New Issue		
1	12.06.20	Revise Ch. 28, 53, 71, 95		
2	23.03.18	Effectivity corrected in Chapter 53. Instrument configuration updated for MSNs 30576 & 30931 in Chapter 95.		
3	23.09.01	Incorporated ECN-212-011 Rev. A. Chapter 95 Item 13 alternate added.		

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **3**
Date: 23.09.01

CHAPTER 01 – INTRODUCTION (01-00-00)

LIST OF EFFECTIVE PAGES

Section	Page	Revision #	Section	Page	Revision #	Section	Page	Revision #
01	1	3	28	5	1	53	13	2
01	2	3	28	6	1	53	14	2
01	3	3	28	7	1	53	15	2
01	4	3	28	8	1	53	16	2
01	5	3	28	9	1	53	17	2
01	6	3	28	10	1	53	18	2
01	7	3	28	11	1	53	19	2
01	8	3	28	12	1	53	20	2
01	9	3	28	13	1	53	21	2
01	10	3	28	14	1	53	22	2
01	11	3	28	15	1	53	23	2
01	12	3	28	16	1	53	24	2
			28	17	1	53	25	2
			28	18	1	53	26	2
08	1	0	28	19	1	53	27	2
						53	28	2
09	1	0	29	1	0	53	29	2
			29	2	0	53	30	2
10	1	0	29	3	0	53	31	2
			29	4	0	53	32	2
11	1	0	29	5	0	53	33	2
11	2	0	29	6	0	53	34	2
11	3	0	29	7	0	53	35	2
			29	8	0	53	36	2
21	1	0	29	9	0	53	37	2
21	2	0				53	38	2
21	3	0	30	1	0	53	39	2
21	4	0				53	40	2
21	5	0	32	1	0	53	41	2
						53	42	2
25	1	0	52	1	0	53	43	2
25	2	0				53	44	2
25	3	0	53	1	2	53	45	2
			53	2	2	53	46	2
26	1	0	53	3	2	53	47	2
26	2	0	53	4	2	53	48	2
26	3	0	53	5	2	53	49	2
26	4	0	53	6	2	53	50	2
26	5	0	53	7	2	53	51	2
			53	8	2	53	52	2
28	1	1	53	9	2	53	53	2
28	2	1	53	10	2	53	54	2
28	3	1	53	11	2	53	55	2
28	4	1	53	12	2	53	56	2

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **3**
Date: 23.09.01

CHAPTER 01 – INTRODUCTION (01-00-00)

LIST OF EFFECTIVE PAGES

Section	Page	Revision #	Section	Page	Revision #	Section	Page	Revision #
53	57	2	67	20	3	71	42	1
53	58	2	67	21	3	71	43	1
53	59	2				71	44	1
53	60	2	71	1	1	71	45	1
53	61	2	71	2	1	71	46	1
53	62	2	71	3	1	71	47	1
			71	4	1	71	48	1
62	1	0	71	5	1	71	49	1
			71	6	1	71	50	1
63	1	0	71	7	1	71	51	1
63	2	0	71	8	1	71	52	1
63	3	0	71	9	1	71	53	1
63	4	0	71	10	1			
63	5	0	71	11	1	76	1	0
63	6	0	71	12	1	76	2	0
63	7	0	71	13	1	76	3	0
63	8	0	71	14	1	76	4	0
63	9	0	71	15	1	76	5	0
63	10	0	71	16	1	76	6	0
63	11	0	71	17	1	76	7	0
			71	18	1	76	8	0
64	1	0	71	19	1	76	9	0
			71	20	1	76	10	0
65	1	0	71	21	1	76	11	0
			71	22	1			
67	1	3	71	23	1	79	1	0
67	2	3	71	24	1	79	2	0
67	3	3	71	25	1	79	3	0
67	4	3	71	26	1	79	4	0
67	5	3	71	27	1	79	5	0
67	6	3	71	28	1	79	6	0
67	7	3	71	29	1	79	7	0
67	8	3	71	30	1	79	8	0
67	9	3	71	31	1	79	9	0
67	10	3	71	32	1	79	10	0
67	11	3	71	33	1	79	11	0
67	12	3	71	34	1	79	12	0
67	13	3	71	35	1	79	13	0
67	14	3	71	36	1			
67	15	3	71	37	1	95	1	3
67	16	3	71	38	1	95	2	3
67	17	3	71	39	1	95	3	3
67	18	3	71	40	1	95	4	3
67	19	3	71	41	1	95	5	3

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **3**

Date: 23.09.01



CHAPTER 01 – INTRODUCTION (01-00-00)

LIST OF EFFECTIVE PAGES

Section	Page	Revision #
95	6	3
95	7	3
95	8	3
95	9	3
95	10	3
96	1	2
96	2	2
97	1	0

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **3**
Date: 23.09.01



CHAPTER 01 – INTRODUCTION (01-00-00)

Customer Feedback

Return via fax to (403) 717-1288

Manual Title: _____

Date of latest Revision: _____

Section; Chapter; Paragraph Affected: _____

Your feedback: _____

Now Reads: _____

Should Read: _____

Your Name: _____

Address: _____

Position: _____ Company: _____

Phone: _____ Fax: _____

Email: _____

CHAPTER 01 – INTRODUCTION (01-00-00)

IPC – Table of Contents

Chapter 01 – Introduction.....	(01-00-00)
Chapter 08 – Weight and Balance	(08-00-00)
Chapter 09 – Towing.....	(09-00-00)
Chapter 10 – Parking and Mooring	(10-00-00)
Chapter 11 – Placards and Markings.....	(11-00-00)
Chapter 21 – Air Distribution (Ventilation).....	(21-00-00)
Chapter 25 – Equipment and Furnishings	(25-00-00)
Chapter 26 – Fire Protection.....	(26-00-00)
Chapter 28 – Fuel System.....	(28-00-00)
Chapter 29 – Hydraulic System	(29-00-00)
Chapter 30 – Ice and Rain Protection.....	(30-00-00)
Chapter 32 – Landing Gear.....	(32-00-00)
Chapter 52 – Doors and Windows	(52-00-00)
Chapter 53 – Fuselage.....	(53-00-00)
Chapter 62 – Main Rotor.....	(62-00-00)
Chapter 63 – Main Rotor Drive System	(63-00-00)
Chapter 64 – Tail Rotor.....	(64-00-00)
Chapter 65 – Tail Rotor Drive System	(65-00-00)
Chapter 67 – Flight Controls	(67-00-00)
Chapter 71 – Power Plant System	(71-00-00)
Chapter 76 – Engine Controls.....	(76-00-00)
Chapter 79 – Engine Oil System.....	(79-00-00)
Chapter 95 – Instrument System	(95-00-00)
Chapter 96 – Electrical System.....	(96-00-00)
Chapter 97 – Avionics	(97-00-00)

CHAPTER 01 – INTRODUCTION (01-00-00)

1.0 Introduction

CAUTION

THIS IPC IS FOR USE IN THE ORDERING OF SPARES AND REPAIR PARTS AND IS NOT INTENDED FOR USE AS A CONFIGURATION CONTROL DOCUMENT OR MAINTENANCE AND INSPECTION CRITERIA MANUAL. ITS SOLE PURPOSE IS FOR THE IDENTIFICATION AND ORDERING OF SPARES.

The figures contained in the IPC portion of this publication consist of an illustration and text page. Illustrations are in exploded form and are arranged in a manner to depict the relationship of the parts listed on the text page. Guidelines are used to further clarify this relationship. Parts outlined by “phantom” lines are shown merely to relate detail parts to assemblies or systems.

2.0 Use of Manual

2.1 General

This publication applies to the Bell Model 212 helicopters that have been modified per STC SH07-28 (Eagle Single) and lists all the parts considered necessary for maintenance or repair of this modified helicopter. It shall be used in conjunction with the Bell 212 Illustrated Parts Catalogue. Where no change exists in a specific area the user is asked to reference the Bell IPC. This publication is intended only to supply part information as it applies to the Bell 212 helicopters modified per TCCA STC SH07-28 (Ref. FAA STC SR002831NY).

2.2 Use of the Manual

This manual is divided into Chapters. Refer to the desired Chapter and using the tabbed pages provided which separate each Chapter, refer to the Table of Contents at the beginning of the desired Chapter to locate the specific subject. It shall be used in conjunction with the Bell 212 Illustrated Parts Catalog. Where no changes exist because of the Eagle Single modification in a specific area of the helicopter the user is asked to reference the Bell 212 Illustrated Parts Catalog. This publication is intended only to supply part information as it applies to the Eagle Single modification per TCCA STC SH07-28 (Ref. FAA STC SR002831NY).

2.3 Updates

All updates to this manual will be provided to any operator who possesses this STC. Additionally the latest revision of this manual is available at www.eaglecopters.com. All changes will be recorded in the Revision Record at the front of this manual.

CHAPTER 01 – INTRODUCTION (01-00-00)

3.0 Part Number Indices**3.1 Eagle Part Number Index**

Part Number	Chapter	Figure	Item
D212-725-1-001	53	6	8
D212-725-1-002	53	6	8
D212-725-1-003	53	6	13
D212-725-1-004	53	6	13
D212-725-1-005	53	11	3
D212-725-1-009	53	19	1
D212-725-1-011	53	17	3
D212-725-1-012	53	17	3
D212-725-1-015	53	3	3
D212-725-1-015	53	4	3
D212-725-1-017A	53	18	2
D212-725-1-017B	53	18	3
D212-725-1-019	95	1	34
D212-725-1-021	95	1	35
D212-725-1-023	95	1	38
D212-725-1-025	67	5	1
D212-725-1-027	67	7	22
D212-725-1-055	53	20	3
D212-725-1-057	53	20	4
D212-725-1-059	53	20	1
D212-725-1-061	53	21	1
D212-725-1-063	53	17	4
D212-725-1-064	53	17	4
D212-725-1-065	53	17	5
D212-725-1-066	53	17	5
D212-725-1-069	53	11	1
D212-725-1-075	53	13	2
D212-725-1-077	53	13	9
D212-725-1-078	53	13	9
D212-725-1-079	53	13	5
D212-725-1-079	53	14	4
D212-725-1-080	53	13	5
D212-725-1-080	53	14	4
D212-725-1-081	53	13	6
D212-725-1-083	53	14	6
D212-725-1-084	53	14	6
D212-725-1-085	53	14	2
D212-725-1-089	53	8	18
D212-725-1-091	53	8	17

Part Number	Chapter	Figure	Item
D212-725-1-093	28	1	24
D212-725-1-093	53	8	29
D212-725-1-095	53	13	7
D212-725-1-097	53	13	8
D212-725-1-099	53	13	10
D212-725-1-101	53	13	12
D212-725-1-101	53	13	14
D212-725-1-103	53	11	2
D212-725-1-105	28	1	31
D212-725-1-105	53	8	27
D212-725-1-107	53	14	1
D212-725-1-109	53	2	7
D212-725-1-109	53	17	1
D212-725-1-110	53	2	7
D212-725-1-110	53	17	1
D212-725-1-111	53	2	11
D212-725-1-111	53	17	2
D212-725-1-113	53	13	17
D212-725-1-114	53	13	17
D212-725-1-115	53	14	3
D212-725-1-117	53	9	1
D212-725-1-119	71	1	62
D212-725-1-120	71	1	61
D212-725-1-123	26	1	8
D212-725-1-133	53	6	10
D212-725-1-133	53	24	1
D212-725-1-135	53	3	2
D212-725-1-148	53	16	19
D212-725-1-149	53	16	2
D212-725-1-151	53	16	12
D212-725-1-153	53	16	7
D212-725-1-155	53	16	5
D212-725-1-157	53	16	16
D212-725-1-159	53	16	6
D212-725-1-161	53	16	17
D212-725-1-163	53	16	4
D212-725-1-165	53	16	13
D212-725-1-167	53	16	11
D212-725-1-169	53	16	9

CHAPTER 01 – INTRODUCTION (01-00-00)

Part Number	Chapter	Figure	Item
D212-725-1-171	53	16	3
D212-725-1-173	53	16	3
D212-725-1-175	53	7	7
D212-725-1-176	53	7	7
D212-725-1-177	53	7	12
D212-725-1-178	53	7	12
D212-725-1-179	53	7	4
D212-725-1-181	53	7	6
D212-725-1-183	53	7	9
D212-725-1-184	53	7	9
D212-725-1-185	53	7	6
D212-725-1-187	53	7	13
D212-725-1-189	53	7	14
D212-725-1-191	53	7	5
D212-725-1-193	53	4	2
D212-725-1-195	28	3	33
D212-725-1-197	53	12	7
D212-725-1-197	53	12	14
D212-725-1-201	53	25	1
D212-725-1-202	53	25	3
D212-725-1-205	95	2	34
D212-725-1-207	95	2	36
D212-725-1-209	95	2	37
D212-725-1-211	53	9	2
D212-725-1-215	53	26	1
D212-725-1-217	53	26	2
D212-725-1-219	53	26	3
D212-725-1-221	53	26	4
D212-725-1-223	53	26	5
D212-725-1-225	53	26	6
D212-725-1-227	71	11	6
D212-725-1-229	53	5	5
D212-725-1-231	53	5	6
D212-725-1-233	53	5	1
D212-725-1-235A	53	8	3
D212-725-1-235B	53	8	8
D212-725-1-235C	53	8	9
D212-725-1-235D	53	8	10
D212-725-1-237A	53	8	4
D212-725-1-237B	53	8	5
D212-725-1-237C	53	8	6
D212-725-1-237D	53	8	7
D212-725-1-237E	53	8	11
D212-725-1-237F	53	8	12
D212-725-1-237G	53	8	13
D212-725-1-237H	53	8	14

Part Number	Chapter	Figure	Item
D212-725-1-237J	53	8	15
D212-725-1-245	67	1	18
D212-725-1-247	67	1	17
D212-725-1-249	28	4	1
D212-725-1-255	53	10	16
D212-725-1-257	71	9	9
D212-725-1-259	53	26	2
D212-725-1-261	53	26	3
D212-725-1-263	53	26	4
D212-725-1-265	53	26	5
D212-725-1-267	53	26	6
D212-725-1-269	53	26	7
D212-725-1-271	28	7	1
D212-725-1-273	28	6	1
D212-725-1-275	53	9	1
D212-725-1-276	53	9	2
D212-725-1-277	53	9	3
D212-725-1-279	53	9	4
D212-725-1-280	53	9	5
D212-725-1-281	53	25	8
D212-725-1-901	67	1	1
D212-725-1-903	53	10	2
D212-725-1-903	53	10	8
D212-725-1-905	21	1	2
D212-725-1-913	28	2	17
D212-725-1-913	53	22	4
D212-725-1-915	28	2	18
D212-725-1-915	53	22	2
D212-725-1-917	28	3	1
D212-725-1-919	76	1	32
D212-725-1-921	79	3	33
D212-725-1-923	26	1	10
D212-725-1-925	26	1	2
D212-725-1-927	28	5	1
D212-725-1-929	76	2	46
D212-725-1-931	26	1	1
D212-725-1-933	53	20	2
D212-725-1-935	79	3	24
D212-725-1-937	53	10	13
D212-725-1-939	53	26	
D212-725-1-941	28	2	17
D212-725-1-941	53	23	4
D212-725-1-943	28	2	18
D212-725-1-943	53	23	2

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **3**
Date: 23.09.01

CHAPTER 01 – INTRODUCTION (01-00-00)

Part Number	Chapter	Figure	Item
D212-725-1-945	28	2	24
D212-725-1-945	28	2	25
D212-725-1-945	53	23	5
D212-725-1-947	67	1	19
D212-725-1-949	21	2	1
D212-725-1-951	53	26	1
D212-725-6-001	11	1	4

Part Number	Chapter	Figure	Item
D212-725-6-003	11	1	2
D212-725-6-005	11	1	3
D212-725-6-007	11	1	1
D212-725-6-009	11	1	6
D212-725-6-011	11	1	7

CHAPTER 01 – INTRODUCTION (01-00-00)

3.2 Eagle Part Number – Bell Part Number Equivalency Chart

Eagle Part Number	Equivalent Bell Part Number
D212-725-1-001	New Part
D212-725-1-002	New Part
D212-725-1-003	New Part
D212-725-1-004	New Part
D212-725-1-005	New Part
D212-725-1-009	New Part
D212-725-1-011	New Part
D212-725-1-012	New Part
D212-725-1-015	New Part
D212-725-1-017A	New Part
D212-725-1-017B	New Part
D212-725-1-019	New Part
D212-725-1-021	New Part
D212-725-1-023	New Part
D212-725-1-025	New Part
D212-725-1-027	New Part
D212-725-1-055	New Part
D212-725-1-057	New Part
D212-725-1-059	New Part
D212-725-1-061	205-032-170-003
D212-725-1-063	New Part
D212-725-1-064	New Part
D212-725-1-065	New Part
D212-725-1-066	New Part
D212-725-1-069	New Part
D212-725-1-075	New Part
D212-725-1-077	New Part
D212-725-1-078	New Part
D212-725-1-079	New Part
D212-725-1-080	New Part
D212-725-1-081	New Part
D212-725-1-083	New Part
D212-725-1-084	New Part
D212-725-1-085	New Part
D212-725-1-089	205-030-499-009
D212-725-1-091	New Part
D212-725-1-093	New Part
D212-725-1-095	New Part
D212-725-1-097	New Part
D212-725-1-099	New Part
D212-725-1-101	NAS43DD5-24
D212-725-1-103	New Part
D212-725-1-105	New Part
D212-725-1-107	New Part
D212-725-1-109	New Part

Eagle Part Number	Equivalent Bell Part Number
D212-725-1-110	New Part
D212-725-1-111	New Part
D212-725-1-113	New Part
D212-725-1-114	New Part
D212-725-1-115	New Part
D212-725-1-117	New Part
D212-725-1-119	205-060-872-001
D212-725-1-120	205-060-872-002
D212-725-1-123	205-061-909-011
D212-725-1-133	New Part
D212-725-1-135	New Part
D212-725-1-149	205-032-107-037
D212-725-1-151	205-032-107-033
D212-725-1-153	205-032-107-019
D212-725-1-155	205-032-107-021
D212-725-1-157	205-032-107-045
D212-725-1-159	205-032-107-029
D212-725-1-161	205-032-107-017
D212-725-1-163	205-032-107-024
D212-725-1-165	205-032-107-027
D212-725-1-167	205-032-107-023
D212-725-1-169	205-032-107-025
D212-725-1-171	205-032-107-047
D212-725-1-173	205-961-316-015
D212-725-1-175	New Part
D212-725-1-176	New Part
D212-725-1-177	New Part
D212-725-1-178	New Part
D212-725-1-179	New Part
D212-725-1-181	New Part
D212-725-1-183	New Part
D212-725-1-184	New Part
D212-725-1-185	New Part
D212-725-1-187	New Part
D212-725-1-189	New Part
D212-725-1-191	New Part
D212-725-1-193	New Part
D212-725-1-195	205-060-919-003
D212-725-1-197	205-060-835-001
D212-725-1-201	New Part
D212-725-1-202	New Part
D212-725-1-205	New Part
D212-725-1-207	New Part
D212-725-1-209	New Part
D212-725-1-211	New Part

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **3**

Date: 23.09.01

CHAPTER 01 – INTRODUCTION (01-00-00)

Eagle Part Number	Equivalent Bell Part Number
D212-725-1-215	New Part
D212-725-1-217	New Part
D212-725-1-219	New Part
D212-725-1-221	New Part
D212-725-1-223	New Part
D212-725-1-225	New Part
D212-725-1-227	New Part
D212-725-1-229	205-032-106-121
D212-725-1-231	New Part
D212-725-1-233	New Part
D212-725-1-235	New Part
D212-725-1-237	New Part
D212-725-1-245	205-001-113-001
D212-725-1-247	205-001-113-003
D212-725-1-249	205-061-642-009
D212-725-1-255	212-030-024-001
D212-725-1-257	New Part
D212-725-1-259	New Part
D212-725-1-261	New Part
D212-725-1-263	New Part
D212-725-1-265	New Part
D212-725-1-267	New Part
D212-725-1-269	New Part
D212-725-1-271	New Part
D212-725-1-273	New Part
D212-725-1-275	205-030-713-021
D212-725-1-276	205-030-713-022
D212-725-1-277	205-030-713-007
D212-725-1-279	205-030-713-013
D212-725-1-280	205-030-713-014
D212-725-1-281	205-060-881-001
D212-725-1-901	New Part

Eagle Part Number	Equivalent Bell Part Number
D212-725-1-903	New Part
D212-725-1-905	New Part
D212-725-1-907	New Part
D212-725-1-913	New Part
D212-725-1-915	New Part
D212-725-1-917	New Part
D212-725-1-919	New Part
D212-725-1-921	205-061-523-001
D212-725-1-923	New Part
D212-725-1-925	New Part
D212-725-1-927	New Part
D212-725-1-929	205-060-722-001
D212-725-1-931	205-061-904-001
D212-725-1-933	New Part
D212-725-1-935	205-032-212-001
D212-725-1-937	212-030-321-001
D212-725-1-939	205-060-881-001
D212-725-1-941	New Part
D212-725-1-943	New Part
D212-725-1-945	New Part
D212-725-1-947	New Part
D212-725-1-949	205-030-100-011
D212-725-1-951	205-030-617-181
D212-725-6-001	New Part
D212-725-6-003	New Part
D212-725-6-005	New Part
D212-725-6-007	New Part
D212-725-6-009	New Part
D212-725-6-011	New Part



CHAPTER 08 – WEIGHT AND BALANCE (08-00-00)

CHAPTER 08 WEIGHT AND BALANCE (08-00-00)

REFER TO BHT-212-IPC

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **0**
Date: 11.06.06



CHAPTER 09 – TOWING (09-00-00)

CHAPTER 09 TOWING (09-00-00)

REFER TO BHT-212-IPC

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **0**
Date: 11.06.06



CHAPTER 10 – PARKING AND MOORING (10-00-00)

CHAPTER 10 PARKING AND MOORING (10-00-00)

REFER TO BHT-212-IPC

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **0**
Date: 11.06.06



CHAPTER 11 – PLACARDS (11-00-00)

CONTENTS – IPC
CHAPTER 11 PLACARDS

Figure Number	Figure Title	Page Number
11-1	Placards	2

CHAPTER 11 – PLACARDS (11-00-00)




Figure 11-1 Placards and Markings



CHAPTER 11 – PLACARDS (11-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 11-1				
1	D212-725-6-007	Placard (Operations Limitations)	1	
2	D212-725-6-003	Placard (Operating Limitations)	1	
3	D212-725-6-005	Placard (EGT VS OAT Limits)	1	
4	D212-725-6-001	Placard (VFR Operations Only)	1	
5	212-070-661-003	Placard (Fuel System Capacity)	2	
6	212-070-661-001	Placard (Fuel System Capacity)	1	
6	D212-725-6-009	Placard (Fuel System Capacity) (Alternate Part)	1	
7	D212-725-6-011	Eagle Single Identification Placard	1	
8	31-064-5EFHP	Placard (Approved Lubricants)	2	
9	31-053-3DFHP	Placard (Hydraulic Reservoir Inside)	2	
10	31-054-4DFHP	Placard (Transmission Oil Access)	2	
11	31-054-32DFHP	Placard (Transmission Capacity)	2	
12	205-076-060-103	Placard (Hydraulic System Servicing)	2	
13	205-076-060-101	Placard (Hydraulic System Cleaning)	2	
14	205-070-818-007	Placard (Engine Oil Tank, Oil Ferry Level)	1	
15	205-070-818-009	Placard (Engine Oil Tank, Oil Normal Level)	1	
16	205-070-818-011	Placard (Engine Oil Tank, Oil Minimum Level)	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0
Date: 11.06.06



CHAPTER 21 – AIR DISTRIBUTION (VENTILATION) (21-00-00)

CONTENTS – IPC
CHAPTER 21 AIR DISTRIBUTION (VENTILATION)

Figure Number	Figure Title	Page Number
21-1	Air Distribution (Heating and Ventilation)	2
21-2	D212-725-1-949 Duct	4

CHAPTER 21 – AIR DISTRIBUTION (VENTILATION) (21-00-00)




Figure 21-1 Air Distribution Installation (Heating and Ventilation)



CHAPTER 21 – AIR DISTRIBUTION (VENTILATION) (21-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 21-1				
1	AN815-16	Fitting	1	
2	D212-725-1-905	Tube Assembly	1	
3	NAS1149F2190J	Washer	1	
4	AN924-16	Nut	1	
5	205-060-438-005	Gasket	2	
6	AN832-16	Fitting	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0
Date: 11.06.06

CHAPTER 21 – AIR DISTRIBUTION (VENTILATION) (21-00-00)




Figure 21-2 D212-725-1-949 Duct



CHAPTER 21 – AIR DISTRIBUTION (VENTILATION) (21-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 21-2				
1	D212-725-1-949	Duct Assembly	1	
1	205-030-100-011	Duct Assembly (Alternate Part)	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0
Date: 11.06.06



CHAPTER 25 – EQUIPMENT (25-00-00)

CONTENTS – IPC
CHAPTER 25 EQUIPMENT

Figure Number	Figure Title	Page Number
25-1	Blanket Installation, Upholstery	2

CHAPTER 25 – EQUIPMENT (25-00-00)





Figure 25-1 Blanket Installation, Upholstery

[illegible]

Revision: **0**
Date: 11.06.06



CHAPTER 26 – FIRE PROTECTION (26-00-00)

CONTENTS – IPC
CHAPTER 26 FIRE PROTECTION

Figure Number	Figure Title	Page Number
26-1	Fire Extinguisher Installation	2
26-2	Fire Detection Installation	4

CHAPTER 26 – FIRE PROTECTION (26-00-00)




Figure 26-1 Fire Extinguisher Installation



CHAPTER 26 – FIRE PROTECTION (26-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 26-1				
1	D212-725-1-931	Tube Assembly	1	
2	D212-725-1-925	Tube Assembly	1	
3	2241-009	Container (Charged to 6 lbs)	1	
4	AN4-6A	Bolt	4	
5	AN970-4	Washer	4	
6	AN960-416L	Washer	16	
7	MS21042L4	Nut	4	
8	D212-725-1-123	Bracket	2	
9	AN4-3A	Bolt	2	
10	D212-725-1-923	Bracket Assembly	1	
11	AN525-10R6	Screw	4	
12	NAS1149C0332R	Washer	4	
13	MS21042L3	Nut	1	
14	NAS1149D0332J	Washer	1	
15	MS21919WDG6	Clamp	1	
16	70-061F098F180A	Hose Assembly	1	
17	NAS43DD3-48N	Spacer	1	
18	NAS1149D0332J	Washer	1	
19	MS27039-1-19	Screw	1	
20	NAS1149F0463P	Washer	2	

CHAPTER 26 – FIRE PROTECTION (26-00-00)




Figure 26-2 Fire Detection Installation



CHAPTER 26 – FIRE PROTECTION (26-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 26-2				
1	MS21069L3	Nutplate	8	
2	NAS1149F0332P	Washer	8	
3	AN525-10R6	Screw	8	
4	30-207-23	Flame Detector	2	
5	205-061-906-003	Gasket	2	
6	MS21069L3	Nutplate	3	
7	NAS1149F0332P	Washer	3	
8	AN525-10R6	Screw	3	
9	30-207-22	Flame Detector	1	
10	205-061-906-001	Gasket	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **0**
Date: 11.06.06

CHAPTER 28 – FUEL SYSTEM (28-00-00)




Figure 28-1 Fuel System Installation (Sheet 1 of 2)

CHAPTER 28 – FUEL SYSTEM (28-00-00)





Figure 28-1 Fuel system Installation (Sheet 2 of 2)

[illegible]

Revision: **1**
Date: 12.06.20



CHAPTER 28 – FUEL SYSTEM (28-00-00)

This page intentionally left blank

CHAPTER 28 – FUEL SYSTEM (28-00-00)




Figure 28-2 Fuel System Installation



CHAPTER 28 – FUEL SYSTEM (28-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 28-2				
1	AN832-5	Union	1	
2	NAS1149D0863J	Washer	1	
3	AN924-5	Nut	1	
4	MS29512-05	Packing, Preformed	1	
5	AN893-5-4	Bushing Reducer	1	
6	205-061-685-001	Tube Assembly	1	
7	458-4D1-6	Valve	1	
8	MS29512-04	Packing, Preformed	1	
9	MS21042L3	Nut	1	
10	NAS1149D0332J	Washer	1	
11	MS35207-264	Screw	1	
12	MS21919WDG12	Clamp	2	
13	MS27039-1-24	Screw	1	
14	NAS1149D0332J	Washer	1	
15	NAS43DD3-70	Spacer	1	
16	MS21919WDG12	Clamp	1	
17	D212-725-1-913	Tube Assembly	1	1
17	D212-725-1-941	Tube Assembly	1	2
18	D212-725-1-915	Tube Assembly	1	1
18	D212-725-1-943	Tube Assembly	1	2
19	AN815-12D	Union	2	
20	MS21042L3	Nut	1	
21	NAS1149D0332J	Washer	1	
22	MS35207-263	Screw	1	
23	MS21919WDG12	Clamp	2	
24	212-060-653-001	Tube Assembly	1	1
24	D212-725-1-945	Tube Assembly	1	2
25	212-060-642-001	Tube Assembly	1	1
25	D212-725-1-945	Tube Assembly	1	2
26	MS35489-20	Grommet	1	
27	MS35489-21	Grommet	1	

UOC Code

1 - S/N 30817, 30576, 30687, 30599, 30931 and 30544

2 - All S/N's except 30817, 30576, 30687, 30599, 30931 and 30544

Date: 12.06.20



CHAPTER 28 – FUEL SYSTEM (28-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 28-3				
1	D212-725-1-917	Tube Assembly	1	
2	AN837-6	Fitting	1	
3	MS29512-06	Packing, Preformed	3	
4	AN917-6	Fitting	1	
5	AN833-6	Elbow	1	
5a	AN832-6	Fitting	1	
5b	NAS1149C0963R	Washer	1	
5c	AN924-6	Nut	3	
6	475C62NWPS	Valve	1	
7	AN924-6	Nut	1	
8	MS29512-06	Packing, Preformed	1	
9	205-061-674-001	Tube Assembly	1	
12	AN833-10	Elbow	1	
13	MS29512-10	Packing, Preformed	1	
14	AN924-10	Nut	1	
15	AN832-10	Union	1	
16	MS29512-10	Packing, Preformed	1	
17	AN924-10	Nut	1	
18	AN939D10	Elbow	1	
19	MS21042L3	Nut	2	
20	NAS1149D0332J	Washer	4	
21	AN3-21A	Bolt	2	
22	MS21042L3	Nut	2	
23	NAS1149D0363J	Washer	10	
24	AN3-24A	Bolt	2	
25	MS20756D16	Flange	2	
26	MS29512-10	Packing, Preformed	2	
27	205-060-616-001	Bearing	2	
28	205-060-612-003	Valve	1	
28	233565	Valve (Alternate Part)	1	
28A	MS29512-10	Packing, Preformed	2	
29	MS21043-3	Nut	3	
30	NAS1149C0332R	Washer	3	
31	NAS1149D0332J	Washer	6	
32	AN3C3A	Bolt	3	
33	D212-725-1-195	Bracket	1	1
34	MS21043-3	Nut	2	
35	NAS1149C0332R	Washer	2	
36	NAS1149D0332J	Washer	4	
37	AN3C24A	Bolt	2	
38	NAS43DD3-56	Spacer	2	
39	AN814-4WL	Plug	2	



CHAPTER 28 – FUEL SYSTEM (28-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 28-3				
40	AN814-4W	Plug	1	
41	MS29512-04	Packing, Preformed	3	
42	205-060-611-003	Manifold	1	
43	AN833-10	Elbow	1	
44	MS29512-10	Packing, Preformed	1	
45	AN924-10	Nut	1	
46	205-061-537-001	Tube Assembly	1	
47	AN737TW34	Clamp	2	
48	205-061-531-019	Shroud	1	
49	205-061-531-015	Shroud	1	
50	BAS520-50G	Transducer	1	1
53	MS29512-04	Packing, Preformed	1	
60	AN3H3A	Bolt	4	
61	NAS1149D0363J	Washer	4	
62	204-040-760-005	Filter Assembly	1	
63	N4309S5-350	Clamp Assembly (Post ASB 205-80-14)	1	
64	200L4-275-75	T-Bolt (Post ASB 205-80-14)	1	
65	204-040-760-011	Head	1	
66	MS29513-237	Packing, Preformed	1	
67	204-040-760-015	Sump Bowl	1	
68	MS29513-024	Packing, Preformed	2	
69	204-040-760-013	Element	1	
70	204-060-670-001	Restrictor	1	2
71	205-061-531-015	Shroud	2	2
72	AN737TW24	Clamp	2	2
73	205-061-537-001	Tube Assembly	1	2
74	AN815-4	Union	1	2
75	MS29512-04	Packing, Preformed	3	2
76	AN924-12J	Nut	1	2
77	NAS1149C1790R	Washer	1	2
78	205-061-686-001	Bracket	1	2
79	NAS1149D0332J	Washer	4	2
80	MS27039-1-05	Screw	4	2
81	130-020-1	Transmitter, Fuel Pressure	1	2
82	MS29512-04	Packing, Preformed	1	2
83	100-016-1	Plug	1	2

UOC Code

1 - All S/N except 30817, 30576, 30687, 30599, 30544 and 30931

2 - S/N 30817, 30576, 30687, 30599, 30544 and 30931

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 1

Date: 12.06.20



CHAPTER 28 – FUEL SYSTEM (28-00-00)

This page intentionally left blank

CHAPTER 28 – FUEL SYSTEM (28-00-00)




Figure 28-4 Fuel System Installation



CHAPTER 28 – FUEL SYSTEM (28-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 28-4				
1	205-061-642-009	Door Assembly	1	
1	D212-725-1-249	Door Assembly (Alternate Part)	1	
2	205-061-684-001	Nut	1	
3	AN814-8D	Plug	1	
4	MS29512-08	Packing, Preformed	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20

CHAPTER 28 – FUEL SYSTEM (28-00-00)




Figure 28-5 Aux Fuel System



CHAPTER 28 – FUEL SYSTEM (28-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 28-5				
1	D212-725-1-927	Tube Assembly (Replaces 212-060-668-1)	1	
2	Connects to	70-010H000T060 Hose Assembly	Ref	
3	Connects to	212-060-667-1 Tube Assembly	Ref	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20

CHAPTER 28 – FUEL SYSTEM (28-00-00)




Figure 28-6 Fwd Interconnect Valve Location



CHAPTER 28 – FUEL SYSTEM (28-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 28-6				
1	D212-725-1-273	Hose Assembly	1	1
2	AN815-8D	Union	1	1

UOC Code

1 – All aircraft serial numbers except S/N 30687, 30931, 30576, 30817, 30599, 30544, 30866, and 30826 unless DSB-D212-725-4 has been incorporated.

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20

CHAPTER 28 – FUEL SYSTEM (28-00-00)




Figure 28-7 Rear Interconnect Valve Location




CHAPTER 28 – FUEL SYSTEM (28-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 28-7				
1	D212-725-1-271	Fitting	1	1
2	MS29513-123	Packing, Preformed	2	1

UOC Code

1 – All aircraft serial numbers except S/N 30687, 30931, 30576, 30817, 30599, 30544, 30866, and 30826, unless DSB-D212-725-4 has been incorporated.



CONTENTS – IPC

CHAPTER 29 HYDRAULICS

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **A**
Date: 11.06.06

CHAPTER 29 – FUSELAGE (29-00-00)




Figure 29-1 Hydraulic System 2 Installation (Sheet 1 of 2)

CHAPTER 29 – FUSELAGE (29-00-00)




Figure 29-1 Hydraulic System 2 Installation (Sheet 2 of 2)



CHAPTER 29 – FUSELAGE (29-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 29-1				
1	205-076-384-001	Tube Assembly	1	
2	MS21907W8	Elbow	1	
3	AN6289D8	Nut	2	
4	MS28778-8	Packing, Preformed	1	
5	MS28773-8	Retainer	1	
6	MS28778-8	Packing, Preformed	1	
7	MS28773-8	Retainer	1	
8	AN939D8	Fitting	1	
9	AN832D8	Fitting	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **A**
Date: 11.06.06



CHAPTER 29 – FUSELAGE (29-00-00)

This page intentionally left blank

CHAPTER 29 – FUSELAGE (29-00-00)




Figure 29-2 Hydraulic System 1 Pressure Switch and Pressure Transducer Installation
(All S/N except 30817, 30576, 30687, 30599 and 30931)



CHAPTER 29 – FUSELAGE (29-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 29-2				
1	205-076-044-007	Pressure Switch	1	
2	MS28778-6	Packing, Preformed	1	
3	AN938D6	Fitting	1	
4	MS28778-6	Packing, Preformed	1	
5	AN893-2D	Fitting	1	
6	MS28778-4	Packing, Preformed	1	
7	BAS-520-1500SG	Pressure Transducer	1	
8	MS28778-6	Packing, Preformed	1	
9	MS21924D6	Fitting	1	
10	AN6389D6	Nut	1	
11	MS28773-06	Retainer	1	
12	MS28778-6	Packing, Preformed	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **A**
Date: 11.06.06

CHAPTER 29 – FUSELAGE (29-00-00)




Figure 29-3 Hydraulic System 2 Pressure Switch and Pressure Transducer Installation
(All S/N except 30817, 30576, 30687, 30599 and 30931)



CHAPTER 29 – FUSELAGE (29-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 29-3				
1	MS28778-6	Packing, Preformed	1	
2	MS28773-06	Retainer	1	
3	AN6289D6	Nut	1	
4	MS21924D6	Fitting	1	
5	MS28778-6	Packing, Preformed	1	
6	205-076-044-007	Pressure Switch	1	
7	MS28778-6	Packing, Preformed	1	
8	AN938D6	Fitting	1	
9	MS28778-6	Packing, Preformed	1	
10	MS28773-6	Retainer	1	
11	AN6289-6D	Nut	1	
12	MS21924W6	Fitting	1	
13	MS28778-6	Packing, Preformed	1	
14	AN939D6	Elbow	1	
15	MS28778-6	Packing, Preformed	1	
16	AN893-2D	Fitting	1	
17	MS28778-4	Packing, Preformed	1	
18	BAS-520-150SG	Pressure Transducer	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **A**
Date: 11.06.06



CHAPTER 30 – ICE AND RAIN PROTECTION (30-00-00)

CHAPTER 30 ICE AND RAIN PROTECTION (30-00-00)

REFER TO BHT-212-IPC

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **0**
Date: 11.06.06



CHAPTER 32 – LANDING GEAR (32-00-00)

CHAPTER 32 LANDING GEAR (32-00-00)

REFER TO BHT-212-IPC

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **0**
Date: 11.06.06



CHAPTER 52 – DOORS AND WINDOWS (52-00-00)

CHAPTER 52 DOORS AND WINDOWS (52-00-00)

REFER TO BHT-212-IPC

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **0**
Date: 11.06.06

CHAPTER 53 – FUSELAGE (53-00-00)

CONTENTS – IPC
CHAPTER 53 FUSELAGE

Figure Number	Figure Title	Page Number
53-1	Roof Assembly	2
53-2	Engine Mount Installation	4
53-3	Belly Skin Installation, (s/n 30687, 30931, 30576 and 30817)	6
53-4	Belly Skin Installation (Effectivity: None)	8
53-5	Belly Skin Installation (All aircraft except S/N 30687, 30931, 30576, and 30817)	10
53-6	Pylon Web (Aircraft s/n 30687, 30931, 30576 and 30817)	12
53-7	Pylon Web (All Aircraft except s/n 30687, 30931, 30576 and 30817)	14
53-8	Engine Deck	16
53-9	Bulkhead Installation	20
53-10	Drain Installation	24
53-11	Bulkhead, Tension Rod, Support Installation and Bulkhead Detail	26
53-12	Engine Side Service Deck	30
53-13	Bulkhead Installation	32
53-14	Bulkhead Installation	34
53-15	Bulkhead and Cover Installation	36
53-16	Oil Cooler Support	38
53-17	Engine Mount Detail	40
53-18	Bulkhead Detail	42
53-19	Idle Stop Mount	46
53-20	Oil Cooler Installation	48
53-21	D212-725-1-061 Bracket Installation	50
53-22	Vent Tube Installation (S/N 30687, 30931, 30576, 30817, 30599 and 30544)	52
53-23	Vent Tube Installation (All S/N's except 30687, 30931, 30576, 30817, 30599 and 30544)	54
53-24	D212-725-1-201 Doubler Installation	56
53-25	D212-725-1-939 Tail Pipe Shield	58
53-26	Roof Installation	60

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-1 Roof Assembly

CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-1				
1	212-030-304-001	Cover Plate Assembly	1	
2	205-030-127-001	Panel Assembly, Cabin Roof, LH	1	
2	2H5-030-127-001	Panel Assembly, Cabin Roof, LH (Alternate Part)	1	
3	205-030-127-003	Panel Assembly, Cabin Roof, RH	1	
3	2H5-030-127-003	Panel Assembly, Cabin Roof, RH (Alternate Part)	1	
4	205-060-827-001	Bracket, Engine Mount Deck Fitting	2	
5	AN3-3A	Bolt	4	
6	NAS1149D0332J	Washer	4	
7	80-005-2-10	Insert	4	

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **2**
Date: 23.03.18

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-2 Engine Mount Installation

CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-2				
1	AN4-23A	Bolt	4	
2	NAS1149F0463P	Washer	4	
3	205-060-139-001	Fitting	1	
4	NAS1149D0463J	Washer	4	
5	MS21042L4	Nut	4	
6	MS24694-S101	Screw	4	
7	D212-725-1-109	Fitting, LH	1	
7	D212-725-1-110	Fitting, RH	1	
8	NAS1149D0463J	Washer	4	
9	MS21042L4	Nut	4	
10	MS24694-S101	Screw	4	
11	D212-725-1-111	Fitting	2	
12	NAS1149D0463J	Washer	4	
13	MS21042L4	Nut	4	

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-3 Belly Skin Installation (s/n 30687, 30931, 30576, and 30817)



CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-3				
1	205-032-158-001	Stiffener, LH	1	
1	205-032-158-002	Stiffener, RH	1	
2	D212-725-1-135	Doubler	1	
3	D212-725-1-015	Angle	2	

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **2**
Date: 23.03.18

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-4 Belly Skin Installation (Effectivity: None)



CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-4				
1	205-032-158-001	Stiffener, LH	1	
1	205-032-158-002	Stiffener, RH	1	
2	D212-725-1-193	Doubler	1	
3	D212-725-1-015	Angle	2	

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **2**
Date: 23.03.18

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-5 Belly Skin Installation (All aircraft except S/N 30687, 30931, 30576, and 30817)



CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-5				
1	D212-725-1-233	Angle, Internal	1	
2	205-032-106-061	Doubler	1	
3	205-032-106-063	Doubler	1	
4	205-032-158-001	Stiffener, LH	1	
4	205-032-158-002	Stiffener, RH	1	
5	D212-725-1-229	Skin	1	
6	D212-725-1-231	Angle	2	

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **2**

Date: 23.03.18

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-6 Pylon Web (Aircraft s/n 30687, 30931, 30576 and 30817)

CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-6				
1	212-030-042-001	Angle, LH	1	
1	212-030-042-002	Angle, RH	1	
2	205-030-628-003	Roof Bracket, LH	1	
2	205-030-628-004	Roof Bracket, RH	1	
3	205-030-163-163	Doubler, LH	1	
3	205-030-164-167	Doubler, RH	1	
4	205-060-208-001	Support, LH	1	
4	205-060-208-002	Support, RH	1	
5	205-030-164-263	Stiffener, LH	1	
5	205-030-163-295	Stiffener, RH	1	
6	205-031-221-001	Cover, LH	1	
6	205-031-221-002	Cover, RH	1	
7	AN3-4A	Bolt	25	
7	MS21069L3	Nutplate	25	
8	D212-725-1-001	Panel, LH	1	
8	D212-725-1-002	Panel, RH	1	
9	1915-5-4	Bolt	13	
9	1943-5	Retainer	13	
9	1950-5	Receptacle	13	
10	D212-725-1-133	Doubler	1	
11	205-030-163-401	Stiffener, LH	1	
11	205-030-164-347	Stiffener, RH	1	
12	205-030-163-103	Attachment, LH	1	
12	205-030-164-103	Attachment, RH	1	
13	D212-725-1-003	Panel, LH	1	
13	D212-725-1-004	Panel, RH	1	
14	SV4P6	Stud Assembly	21	
15	V4-106	Retainer	21	
15	50-027-1	Retainer (Alternate Part)	21	
16	V4-109	Receptacle	21	
16	50-017-1	Receptacle (Alternate Part)	21	
17	V4-116-62	Shim	21	
17	50-030-1	Shim (Alternate Part)	21	

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-7 Pylon Web (All Aircraft except s/n 30687, 30931, 30576 and 30817)

CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-7				
1	205-060-208-001	Support, LH	1	
1	205-060-208-002	Support, RH	1	
2	205-030-919-041	Channel, LH	1	
2	205-030-919-042	Channel, RH	1	
3	205-030-919-117	Bracket, LH	1	
3	205-030-919-121	Bracket, LH	1	
3	205-030-919-118	Bracket, RH	1	
3	205-030-919-122	Bracket, RH	1	
4	D212-725-1-179	Angle	1	
5	D212-725-1-191	Shim	1	
6	D212-725-1-181	Angle, LH	1	
6	D212-725-1-185	Angle, RH	1	
7	D212-725-1-175	Web, LH	1	
7	D212-725-1-176	Web, RH	1	
8	205-030-163-103	Attachment, LH	1	
8	205-030-164-103	Attachment, RH	1	
9	D212-725-1-183	Attachment, LH	1	
9	D212-725-1-184	Attachment, RH	1	
10	205-030-163-401	Stiffener, LH	1	
10	205-030-164-347	Stiffener, RH	1	
11	212-030-163-239	Doubler, LH	1	
11	212-030-163-217	Doubler, RH	1	
12	D212-725-1-177	Cover, LH	1	
12	D212-725-1-178	Cover, RH	1	
13	D212-725-1-187	Packer	1	
14	D212-725-1-189	Filler	1	
15	212-030-163-247	Web, LH	1	
15	212-030-163-261	Web, LH	1	
15	212-030-164-229	Web, RH	1	
15	212-030-164-235	Web, RH	1	
16	205-030-163-163	Support, LH	1	
16	205-030-164-167	Support, RH	1	
17	205-030-163-295	Stiffener, LH	1	
17	205-030-164-263	Stiffener, RH	1	
18	212-030-163-087	Attachment, LH	1	
18	212-030-163-409	Attachment, LH	1	
18	212-030-164-083	Attachment, RH	1	
19	205-060-208-001	Bracket, LH	1	
19	205-060-208-002	Bracket, RH	1	

Figure 53-8 Engine Deck (Sheet 1 of 2)

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-8 Engine Deck (Sheet 2 of 2)

CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-8				
1	212-030-108-007	Filler Assembly	1	
2	212-030-108-005	Filler Assembly	1	
3	D212-725-1-235A	Angle – made from D212-725-1-235	1	
4	D212-725-1-237A	Angle – made from D212-725-1-237	1	
5	D212-725-1-237B	Angle – made from D212-725-1-237	1	
6	D212-725-1-237C	Angle – made from D212-725-1-237	1	
7	D212-725-1-237D	Angle – made from D212-725-1-237	1	
8	D212-725-1-235B	Angle – made from D212-725-1-235	1	
9	D212-725-1-235C	Angle – made from D212-725-1-235	1	
10	D212-725-1-235D	Angle – made from D212-725-1-235	1	
11	D212-725-1-237E	Angle – made from D212-725-1-237	1	
12	D212-725-1-237F	Angle – made from D212-725-1-237	1	
13	D212-725-1-237G	Angle – made from D212-725-1-237	1	
14	D212-725-1-237H	Angle – made from D212-725-1-237	1	
15	D212-725-1-237J	Angle – made from D212-725-1-237	1	
16	MS21069K3	Nutplate	12	
17	D212-725-1-091	Angle	1	
18	D212-725-1-089	Strap	1	
19	AN525-10R6	Screw	12	
20	NAS1474A3	Nutplate	12	
21	205-030-827-011	Door	1	
22	MS21069L3	Nutplate	5	
23	80-005-2-8	Insert	12	
24	80-004-2-12	Insert	1	
25	80-004-2-8	Insert	3	
26	80-004-2-8	Insert	6	
27	D212-725-1-105	Bushing	4	
28	80-005-2-12	Insert	8	
29	D212-725-1-093	Union	2	
30	AN924-8J	Nut	4	
32	80-011-P12F1-9	Plug	4	
33	80-011-S12F12-9	Sleeve	4	
34	P102F25-1	Plug	3	
34	P102D25-1	Plug	3	
35	80-011-S12F12-0	Sleeve	3	
36	80-004-2-12	Insert	3	
37	205-031-097-099	Engine Deck	1	
37	2H5-031-097-099	Engine Deck (Alternate Part)	1	



CHAPTER 53 – FUSELAGE (53-00-00)

This page intentionally left blank

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-9 Bulkhead Installation (Sheet 1 of 2)

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-9 Bulkhead Installation (Sheet 2 of 2)

CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-9				
1	D212-725-1-275	Receptacle Clip	1	
2	D212-725-1-276	Receptacle Clip	1	
3	D212-725-1-277	Receptacle Clip	2	
4	D212-725-1-279	Bracket, LH	1	
5	D212-725-1-280	Bracket, RH	1	
6	205-030-712-017	Plate	2	
7	205-030-712-041	Plate	1	
8	205-030-712-043	Plate	1	
9	212-030-156-017	Clip	2	
10	212-030-156-037	Clip, RH	1	
11	212-030-156-038	Clip, LH	1	
12	212-030-156-117	Doubler	1	
13	212-030-156-119	Doubler	1	
14	212-030-156-125	Stiffener	2	
15	212-030-156-129	Stiffener	2	
16	D212-725-1-117	Fairlead Bracket	1	
17	D212-725-1-211	Doubler	1	
18	205-030-713-075	Aft Bulkhead	1	



CHAPTER 53 – FUSELAGE (53-00-00)

This page intentionally left blank

CHAPTER 53 – FUSELAGE (53-00-00)





Figure 53-10 Drain Installation

CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-10				
1	212-030-323-003	Fitting	1	
2	D212-725-1-903	Tube Assembly	1	
3	AN924-10J	Nut	1	
4	AN833-10J	Elbow	1	
5	212-030-322-001	Tube Assembly	1	
6	MS35489-17	Grommet	1	
7	212-030-323-003	Fitting	1	
8	D212-725-1-903	Tube Assembly	1	
9	AN924-10J	Nut	1	
10	AN833-10J	Elbow	1	
11	212-030-321-001	Tube Assembly	1	
12	MS35489-17	Grommet	1	
13	D212-725-1-937	Tube Assembly	1	
14	MS35489-17	Grommet	1	
15	212-030-325-001	Tube Assembly	1	
16	D212-725-1-255	Union	2	
16	212-030-024-001	Union (Alternate Part)	2	

CHAPTER 53 – FUSELAGE (53-00-00)






Figure 53-11 Bulkhead, Tension Rod, Support Installation and Bulkhead Detail (Sheet 1 of 2)

CHAPTER 53 – FUSELAGE (53-00-00)



C


LOOKING AFT AT STA 211



C

LOOKING FWD AT STA 211

Figure 53-11 Bulkhead, Tension Rod, Support Installation and Bulkhead Detail (Sheet 2 of 2)

[illegible]

Revision: **2**
Date: 23.03.18



CHAPTER 53 – FUSELAGE (53-00-00)

This page intentionally left blank

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-12 Engine Side Service Decks

CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-12				
1	80-004-2-8	Insert	8	
2	80-005-2-8	Insert	4	
3	MS21069L3	Nutplate	2	
4	MS21069L3	Nutplate	2	
5	100-046S-32B1	Plug Button	1	
6	80-004-3-8	Insert	2	
7	205-060-835-001	Bracket	1	
7	D212-725-1-197	Bracket (Alternate Part)	1	
8	205-030-280-047	Deck Assembly	1	
8	205-030-280-089	Deck Assembly (Alternate Part)	1	
9	205-030-279-045	Gutter (Made from 40-090-1)	1	
9	40-090-1	Gutter	1	
10	204-032-681-001	Drain Plug	1	
11	80-005-2-8	Insert	4	
12	MS21042L3	Nut	6	
13	AN525-10R7	Screw	6	
14	205-060-835-001	Bracket	1	
14	D212-725-1-197	Bracket (Alternate Part)	1	
15	205-030-279-045	Gutter (Made form 40-090-1)	1	
15	40-090-1	Gutter	1	
16	205-030-279-035	Cover	1	
17	205-030-279-079	Deck Assembly	1	

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-13 Bulkhead Installation

CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-13				
1	205-030-407-151	Support, LH	1	
1	205-030-407-152	Support, RH	1	
2	D212-725-1-075	Bracket	1	
3	205-030-407-153	Support, LH	1	
3	205-030-407-154	Support, RH	1	
4	AN3-4A	Bolt	1	
4	NAS1149D0332J	Washer	2	
4	MS21042L3	Nut	1	
5	D212-725-1-079	Gusset, LH	1	
5	D212-725-1-080	Gusset, RH	1	
6	D212-725-1-081	Support	1	
7	D212-725-1-095	Radius Block	1	
8	D212-725-1-097	Packer	1	
9	D212-725-1-077	Gusset, LH	1	
9	D212-725-1-078	Gusset, RH	1	
10	D212-725-1-099	Radius Block	1	
11	NAS1473-A5	Nutplate	1	
12	D212-725-1-101	Spacer	1	
13	NAS43DD5-24	Spacer (Alternate Part)	1	
14	D212-725-1-101	Spacer	1	
15	MS21069L3	Nutplate	9	
16	205-030-411-011	Bracket	1	
16	205-030-411-103	Bracket (Alternate Part)	1	
17	D212-725-1-113	Gusset, LH	1	
17	D212-725-1-114	Gusset, RH	1	

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-14 Bulkhead Installation

CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-14				
1	D212-725-1-107	Angle	1	
2	D212-725-1-085	Bracket	1	
3	D212-725-1-115	Angle	1	
4	D212-725-1-079	Bracket, LH	1	
4	D212-725-1-080	Bracket, RH	1	
5	205-030-407-421	Angle, LH	1	
5	205-030-407-422	Angle, RH	1	
6	D212-725-1-083	Shelf Splice, LH	1	
6	D212-725-1-084	Shelf Splice, RH	1	

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-15 Bulkhead and Cover Installation

[illegible]

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **2**
Date: 23.03.18

CHAPTER 53 – FUSELAGE (53-00-00)





Figure 53-16 Oil Cooler Support

CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-16				
1	MS21075L3	Nutplate	3	
2	205-032-107-037	Support	1	
2	D212-725-1-149	Support (Alternate Part)	1	
3	205-032-107-047	Doubler	1	
3	D212-725-1-171	Doubler (Alternate Part)	1	
3	D212-725-1-173	Bracket	1	
4	205-032-107-024	Clip, RH	1	
4	D212-725-1-163	Clip, RH (Alternate Part)	1	
5	205-032-107-021	Support	1	
5	D212-725-1-155	Support (Alternate Part)	1	
6	205-032-107-029	Clip	1	
6	D212-725-1-159	Clip (Alternate Part)	1	
7	205-032-107-019	Support	1	
7	D212-725-1-153	Support (Alternate Part)	1	
8	MS21075L3	Nutplate	4	
9	205-032-107-025	Clip	1	
9	D212-725-1-169	Clip (Alternate Part)	1	
10	MS21075L3	Nutplate	3	
11	205-032-107-023	Clip, LH	1	
11	D212-725-1-167	Clip, LH (Alternate Part)	1	
12	205-032-107-033	Support	1	
12	D212-725-1-151	Support (Alternate Part)	1	
13	205-032-107-027	Support	1	
13	D212-725-1-165	Support (Alternate Part)	1	
14	205-032-107-043	Web	1	
15	MS21075L3	Nutplate	6	
16	205-032-107-045	Support	1	
16	D212-725-1-157	Support (Alternate Part)	1	
17	205-032-107-017	Stiffener	2	
17	D212-725-1-161	Stiffener (Alternate Part)	2	
18	205-032-107-015	Web	1	
19	205-032-107-035	Support	1	
20	205-032-107-031	Web	1	

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-17 Engine Mount Detail

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **2**
Date: 23.03.18



CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-17				
1	D212-725-1-109	Engine Mount, Aft LH	1	
1	D212-725-1-110	Engine Mount, Aft RH	1	
2	D212-725-1-111	Engine Mount Fwd	2	
3	D212-725-1-011	Angle, LH	1	
3	D212-725-1-012	Angle, RH	1	
4	D212-725-1-063	Stiffener, LH	1	
4	D212-725-1-064	Stiffener, RH	1	
5	D212-725-1-065	Stiffener, LH	1	
5	D212-725-1-066	Stiffener, RH	1	

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **2**

Date: 23.03.18

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-18 Bulkhead Detail (Sheet 1 of 2)

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-18 Bulkhead Detail (Sheet 2 of 2)



CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-18				
1	212-030-222-007	Bulkhead	1	
1	212-030-222-011	Bulkhead (Alternate Part)	1	
1	212-030-222-047	Bulkhead (Alternate Part)	1	
1	212-030-222-073	Bulkhead (Alternate Part)	1	
1	212-030-222-103	Bulkhead (Alternate Part)	1	
2	D212-725-1-017A	Doubler	1	
3	D212-725-1-017B	Doubler (S/N 30687 Only)	1	

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **2**
Date: 23.03.18



CHAPTER 53 – FUSELAGE (53-00-00)

This page intentionally left blank

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-19 Idle Stop Mount



CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-19				
1	D212-725-1-009	Idle Stop Mount	1	

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **2**
Date: 23.03.18

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-20 Oil Cooler Installation

CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-20				
1	D212-725-1-059	Packer	1	
2	D212-725-1-933	Tube Assembly	1	
3	D212-725-1-055	Angle	1	
4	D212-725-1-057	Bracket	1	
5	MS21919WDG04	Clamp	3	
6	AN3-3A	Bolt	3	
7	NAS1149D0363J	Washer	6	
8	MS21042L3	Nut	3	
9	204-062-540-001	Turbine Fan Assembly	1	
10	80-004-2-10	Insert	3	
11	AN3-3A	Bolt	3	
12	NAS1149D0363J	Washer	3	

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **2**
Date: 23.03.18

CHAPTER 53 – FUSELAGE (53-00-00)





Figure 53-21 D212-725-1-061 Bracket Installation

[illegible]

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **2**
Date: 23.03.18

CHAPTER 53 – FUSELAGE (53-00-00)





Figure 53-22 Vent Tube Installation
(S/N 30687, 30931, 30576, 30817, 30599, and 30544)

[illegible]

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **2**
Date: 23.03.18

CHAPTER 53 – FUSELAGE (53-00-00)





Figure 53-23 Vent Tube Installation
(All S/N's Except 30687, 30931, 30576, 30817, 30599 and 30544)

[illegible]

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **2**
Date: 23.03.18

CHAPTER 53 – FUSELAGE (53-00-00)





Figure 53-24 D212-725-1-201 Doubler Installation

[illegible]

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **2**
Date: 23.03.18

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-25 D212-725-1-939 Tail Pipe Shield

CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-25				
	D212-725-1-939	Tail Pipe Shield Assembly	1	
1	D212-725-1-215	Shield Tail Pipe	1	
2	D212-725-1-217	Web	1	
3	D212-725-1-219	Arc Seal Retainer	1	
4	D212-725-1-221	Gusset	1	
5	D212-725-1-223	Angle	1	
6	D212-725-1-225	Seal Retainer	2	
7	120-104-1	Seal	A/R	
8	D212-725-1-281	Doubler	1	

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **2**
Date: 23.03.18

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-26 Roof Installation, Cabin (Sheet 1 of 2)

CHAPTER 53 – FUSELAGE (53-00-00)




Figure 53-26 Roof Installation, Cabin (Sheet 2 of 2)

CHAPTER 53 – FUSELAGE (53-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 53-26				
1	205-030-617-181	Frame/Web Assembly	1	
1	D212-725-1-951	Frame/Web Assembly (Alternate Part)	1	
2	D212-725-1-259	Web	1	
3	D212-725-1-261	Packer	1	
4	D212-725-1-263	Angle	1	
5	D212-725-1-265	Angle	6	
6	D212-725-1-267	Packer	1	
7	D212-725-1-269	Packer	1	
8	MS20470AD4-3	Rivet	18	
9	MS20470AD4-4	Rivet	2	
10	MS20470AD4-10	Rivet	33	
11	PR-35	Dzus Rail	(A/R)	



CHAPTER 62 – MAIN ROTOR (62-00-00)

CHAPTER 62 MAIN ROTOR (62-00-00)

REFER TO BHT-212-IPC

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **0**
Date: 11.06.06



CHAPTER 63 – MAIN ROTOR DRIVE SYSTEM (63-00-00)

CONTENTS – IPC
CHAPTER 63 MAIN ROTOR DRIVE SYSTEM

Figure Number	Figure Title	Page Number
63-1	Oil Cooler Installation, Transmission	2
63-2	Driveshaft Installation, Engine to Transmission	4
63-3	Transmission and Quill Assembly	6
63-4	205-040-263-101 Quill Assembly	8
63-5	205-040-263-111 Quill Assembly	10

CHAPTER 63 – MAIN ROTOR DRIVE SYSTEM (63-00-00)




Figure 63-1 Oil Cooler Installation, Transmission

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0

Date: 11.06.06



CHAPTER 63 – MAIN ROTOR DRIVE SYSTEM (63-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 63-1				
4A	MS21042L3	Nut	1	
4B	NAS1149D0332J	Washer	1	
4C	MS35207-261	Screw	1	
5	MS21919WDG10	Clamp	2	
6	205-040-214-001	Tube Assembly	1	
6	205-040-248-101	Tube Assembly	1	
23	AN821-10D	Elbow	2	
24	MS21042L3	Nut	8	
25	NAS1149D0332J	Washer	8	
26	MS35207-264	Screw	4	
27	MS35207-261	Screw	4	
28	NAS43DD3-16	Spacer	4	
29	AN743-12	Bracket	2	
30	MS21919WDG10	Clamp	4	
31	AN743-7	Bracket	1	
32	412-040-244-101	Tube Assembly	1	
33	205-040-147-001	Tube Assembly	1	
34	MS21042L3	Nut	1	
35	NAS1149D0332J	Washer	1	
36	MS35207-262	Screw	1	
37	MS21919WDG10	Clamp	2	
38	MS21042L3	Nut	1	
39	NAS1149D0332J	Washer	1	
40	MS35207-262	Screw	1	
41	MS21919WDG10	Clamp	1	
42	MS21919WDG16	Clamp	1	
43	205-040-221-001	Tube Assembly	1	
44	205-040-220-001	Tube Assembly	1	
44	205-040-224-001	Tube Assembly	1	
45	AN815-10D	Union	1	
46	205-040-222-001	Tube Assembly	1	
46	205-040-223-001	Tube Assembly	1	
47	AN938D10	Tee	2	
48	AN815-10D	Union	6	
49	AN893-121D	Bushing	2	
50	M83248/1-910	Packing, Preformed	8	
51	AN924-6D	Nut	2	
52	212-040-232-001	Valve	2	
53	M83248/1-906	Packing, Preformed	2	
54	MS35489-11	Grommet	2	
55	205-040-151-001	Tube Assembly	2	
56	AN939-10	Fitting	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0

Date: 11.06.06

CHAPTER 63 – MAIN ROTOR DRIVE SYSTEM (63-00-00)




Figure 63-2 Driveshaft Installation, Engine to Transmission

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0

Date: 11.06.06



CHAPTER 63 – MAIN ROTOR DRIVE SYSTEM (63-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 63-2				
1	MS24665-154	Pin, Cotter	4	
1A	AN310-5	Nut	4	
2	NAS1149F0532P	Washer (Note 1)	4	
3	NAS1149F0563P	Washer	4	
4	204-040-717-001	Pivot	8	
5	MS20002C5	Washer	4	
6	204-040-624-001	Bolt	4	
7	204-040-716-005	Coupling Set	2	
8	204-040-433-101	Driveshaft Assembly	1	
9	204-040-813-001	Bolt (Note 2) (s/n 30003 thru 30272)	1	
9	204-040-813-101	Bolt (Note 2)	1	
10	204-040-814-003	Washer (Note 2) (s/n 30003 thru 30272)	1	
10	204-040-814-001	Washer (Note 2)	1	
11	204-040-812-003	Adapter	1	
	Note 1: Minimum quantity shown, refer to Eagle Single Maintenance Manual for specific fit.			
	Note 2: Replace 204-040-813-001 bolt and 204-040-814-003 washer as a unit using 204-070-813-101 bolt and 204-040-814-001 washer as a unit.			

CHAPTER 63 – MAIN ROTOR DRIVE SYSTEM (63-00-00)




Figure 63-3 Transmission and Quill Assembly



CHAPTER 63 – MAIN ROTOR DRIVE SYSTEM (63-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 63-3				
1	212-040-001-115	Transmission Assembly	1	
1	212-040-001-043	Transmission Assembly	1	
1	212-040-001-123	Transmission Assembly	1	
1	212-040-001-059	Transmission Assembly	1	
1	212-040-001-179	Transmission Assembly	1	
2	205-040-263-101	Input Quill Assembly	1	2
2	205-040-263-111	Input Quill Assembly	1	1

UOC Code

- 1 – S/N 30687 Only
- 2 – All S/N's Except 30687

CHAPTER 63 – MAIN ROTOR DRIVE SYSTEM (63-00-00)




Figure 63-4 205-040-263-101 Quill Assembly

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0

Date: 11.06.06



CHAPTER 63 – MAIN ROTOR DRIVE SYSTEM (63-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 63-4				
1	M27426-3213B	Retainer	1	
2	204-040-629-005	Retainer Assembly	1	
3	204-040-640-001	Packing, Preformed	1	
4	205-040-242-001	Bearing	2	
5	204-040-183-001	Spring	1	
6	204-040-184-001	Nut	1	
7	205-040-232-101	Race	1	
8	204-040-190-101	Race	1	
9	205-040-250-103	Clutch Assembly	1	
10	205-040-237-001	Shield	1	
10A	214-040-867-101	Sleeve	1	
10B	212-340-113-101	Seal	1	
11	M27426-3213D	Retainer	1	
13	204-040-700-101	Pinion	1	
14	214-040-097-003	Sleeve	1	
15	M83248/1-163	Packing, Preformed	1	
16	214-040-098-001	Shim	1	
17	214-040-118-001	Bearing	1	
18	214-040-718-011	Cap Assembly	1	
19	M83248/1-906	Packing, Preformed	1	
20	AN814-6WL	Plug	1	
21	REA032	Nut	3	
22	NAS561P4-6	Pin	1	
23	MS35266-80	Screw	3	
24	NAS1149D0463J	Washer	3	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **0**
Date: 11.06.06

CHAPTER 63 – MAIN ROTOR DRIVE SYSTEM (63-00-00)




Figure 63-5 205-040-263-111 Quill Assembly
(S/N 30687 Only)

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **0**

Date: 11.06.06



CHAPTER 63 – MAIN ROTOR DRIVE SYSTEM (63-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 63-5				
1	M27426-3213B	Retainer	1	
2	204-040-629-005	Retainer Assembly	1	
3	204-040-640-001	Packing, Preformed	1	
4	205-040-242-001	Bearing	2	
5	204-040-190-001	Race	1	
6	204-040-183-001	Spring	1	
7	204-040-184-001	Nut	1	
9	205-040-232-101	Race	1	
10	MS27425-3213D	Retainer	1	
11	205-040-237-001	Shield	1	
11A	214-040-867-101	Sleeve	1	
11B	212-340-113-101	Seal	1	
13	205-040-250-103	Clutch	1	
14	204-040-700-101	Pinion	1	
15	AN310-4	Nut	6	
16	NAS1149F0463P	Washer	6	
17	204-040-148-003	Plate	1	
18	205-040-246-003	Bearing	1	
19	204-040-175-001	Shim	1	
20	AN814-6WL	Plug	1	
21	M83248/1-906	Packing, Preformed	1	
22	205-040-256-007	Sleeve	1	
23	REA-048	Nut	3	
24	MS24693S4	Screw	3	
25	205-040-256-005	Plate (Made from 204-040-358-001)	1	
25	204-040-358-001	Shim Plate	1	
26	BH10	Stud	6	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0
Date: 11.06.06



CHAPTER 64 – TAIL ROTOR (64-00-00)

CHAPTER 64 TAIL ROTOR (64-00-00)

REFER TO BHT-212-IPC

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **0**
Date: 11.06.06



CHAPTER 65 – TAIL ROTOR DRIVE SYSTEM (65-00-00)

CHAPTER 65 TAIL ROTOR DRIVE SYSTEM (65-00-00)

REFER TO BHT-212-IPC

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **0**
Date: 11.06.06

CHAPTER 67 – FLIGHT CONTROLS (67-00-00)

CONTENTS – IPC
CHAPTER 67 FLIGHT CONTROLS

Figure Number	Figure Title	Page Number
67-1	Collective Control Installation – Forward Cabin	2
67-2	Collective Control Installation – Servo	4
67-3	Collective Installation – Jackshaft	6
67-4	Collective Head Installation – Pilot	8
67-5	Collective Stick – Pilot	10
67-6	Collective Head Installation – Co-Pilot	12
67-7	Collective Stick – Co-Pilot	16
67-8	Elbow and Support Assembly – Co-Pilot	18
67-9	Control Installation, Anti-Torque – (Aircraft s/n 30817, 30576, 30687, 30599 and 30931)	20

CHAPTER 67 – FLIGHT CONTROLS (67-00-00)




Figure 67-1 Collective Installation – Forward Cabin

CHAPTER 67 – FLIGHT CONTROLS (67-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 67-1				
1	D212-725-1-901	Bellcrank Assembly	1	
2	205-001-310-001	Bolt	1	
3	NAS1149D0563J	Washer	2	
4	MS14144L5	Nut	1	
5	AN174-14	Bolt	1	
6	NAS1149D0463J	Washer	2	
7	MS14144L4	Nut	1	
8	20-058-4S15D	Bolt	1	
9	NAS1149D0463J	Washer	2	
10	MS14144L4	Nut	1	
11	AN173-12	Bolt	1	
12	NAS1149D0363J	Washer	2	
13	AN310-3	Nut	1	
14	MS24665-152	Pin, Cotter	4	
15	MS27039-1-15	Screw	2	
16	NAS1149D0332J	Washer	2	
17	D212-725-1-247	Retainer	1	
18	D212-725-1-245	Cam	1	
19	D212-725-1-947	Cam Assembly	1	

CHAPTER 67 – FLIGHT CONTROLS (67-00-00)




Figure 67-2 Collective Installation – Servo



CHAPTER 67 – FLIGHT CONTROLS (67-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 67-2				
1	212-001-303-003	Support Assembly	1	

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **3**
Date: 23.09.01

CHAPTER 67 – FLIGHT CONTROLS (67-00-00)




Figure 67-3 Collective Installation - Jackshaft



CHAPTER 67 – FLIGHT CONTROLS (67-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 67-3				
1	212-001-062-001	Tube Assembly (Ref)	1	
2	212-001-126-005	Bellcrank Assembly (Ref)	1	
3	212-001-062-001	Tube Assembly (Ref)	1	
4	NAS43DD4-56	Spacer	1	
5	212-001-111-001	Gear Sector Assembly	1	

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **3**
Date: 23.09.01

CHAPTER 67 – FLIGHT CONTROLS (67-00-00)





Figure 67-4 Collective Head Installation – Pilot

[illegible]

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD. •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **3**
Date: 23.09.01

CHAPTER 67 – FLIGHT CONTROLS (67-00-00)




Figure 67-5 Collective Stick – Pilot



CHAPTER 67 – FLIGHT CONTROLS (67-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 67-5				
1	D212-725-1-025	Spacer	1	1
2	NAS561C4-24	Pin	1	
3	NAS44DD4-56	Spacer	1	
4	212-001-110-001	Gear Sector Assembly	1	

UOC Code

1 - S/N 30817 Only

CHAPTER 67 – FLIGHT CONTROLS (67-00-00)




Figure 67-6 Collective Head Installation – Co-Pilot



CHAPTER 67 – FLIGHT CONTROLS (67-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 67-6				
1	201-001-296-007	Switch Box Assembly	1	
1A	NAS561C6-24	Pin	1	
2	NAS1149F1632P	Washer	2	
3	204-001-156-001	Washer	5	
4	MS21042L3	Nut	1	
5	NAS1149D0363J	Washer	2	
6	MS35207-264	Screw	1	
7	MS21919WDG28	Clamp	1	
8	MS21919WDG5	Clamp	1	
9	MS24693BB50	Screw	1	
10	MS24693-BB73	Screw	2	
11	204-001-297-001	Cover Assembly	1	
12	MS35489-9	Grommet	1	
13	204-001-286-001	Nameplate	1	
17	MS35206-245	Screw	3	
18	NAS1149DN832J	Washer	3	
20	MS35198-17	Screw	2	
21	MS35336-3	Washer	2	
25	120-0071-1	Switch	1	
26	MS25089-3C	Switch	1	
27	C100E2-39	Switch	1	
28	MS25224-1	Switch Guard	1	
29	MS24523-23	Switch	1	
30	AN523-1-82	Pin	1	
31	NAS1149DN232J	Washer	2	
32	204-001-273-001	Trigger	1	
33	MS35649-282	Nut	1	
34	10W4-2	Washer	1	
35	AN565F8H10	Setscrew	1	
36	H20078	Switch	1	
36	2PB744T	Switch	1	
36	2PB744TZ	Switch	1	
37	5101-50MD	Retainer	1	
37	MS16628-1050	Retainer	1	
38	204-001-251-001	Washer	1	
39	M83461/1-112	Packing, Preformed	1	
44	204-001-250-001	Conduit	1	
45	204-075-423-003	Cable Assembly	1	
46	204-001-243-001	Box Assembly	1	
47	MS122199	Insert	1	
48	MS122079	Insert	1	

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: 3

Date: 23.09.01



CHAPTER 67 – FLIGHT CONTROLS (67-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 67-6				
49	MS122240	Insert	2	
50	204-001-248-001	Insert	1	



CHAPTER 67 – FLIGHT CONTROLS (67-00-00)

This page intentionally left blank

Figure 1 is an exploded perspective view of a medical device assembly. The assembly includes a handle (18) connected to a proximal housing (5) and a distal housing (23). A central shaft (21) passes through the housing, with a distal tip (20) and a proximal tip (19). A control cable (16) is connected to the proximal housing and a control knob (17). A distal control cable (12) is connected to the distal housing and a distal control knob (13). A distal control cable (25) is also shown.

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

[illegible]

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **3**
Date: 23.09.01

CHAPTER 67 – FLIGHT CONTROLS (67-00-00)




Figure 67-8 Elbow and Support Assembly – Co-Pilot

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **3**
Date: 23.09.01



CHAPTER 67 – FLIGHT CONTROLS (67-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 67-8				
1	NAS43DD4-56	Spacer	1	
2	212-001-110-001	Gear Sector Assembly	1	

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **3**
Date: 23.09.01

CHAPTER 67 – FLIGHT CONTROLS (67-00-00)




Figure 67-9 Control Installation, Anti-Torque
(Aircraft s/n 30817, 30576, 30687, 30599 and 30931)

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **3**
Date: 23.09.01



CHAPTER 67 – FLIGHT CONTROLS (67-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 67-9				
1	MS21042L4	Nut	1	
2	NAS1149D0463J	Washer	2	
3	205-001-767-001	Eyebolt	1	
4	205-001-767-003	Eyebolt	1	
5	NAS1149D0463J	Washer	2	
6	MS21042L4	Nut	1	
7	205-001-769-001	Strut Assembly	1	

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM EAGLE COPTERS MAINTENANCE LTD.

Revision: **3**
Date: 23.09.01



CHAPTER 71 – POWER PLANT (71-00-00)

**CONTENTS – IPC
CHAPTER 71 POWER PLANT**

Figure Number	Figure Title	Page Number
71-1	Cowl Installation	2
71-2	Cowl Installation	6
71-3	Cowl Installation	8
71-4	Cowl Installation	12
71-5	Cowl Installation	16
71-6	Power Plant Installation	20
71-7	Engine Assembly	22
71-8	Engine Assembly (s/n 30817, 30576, 30687, 30599 and 30931)	26
71-9	Engine Assembly (all s/n except 30817, 30576, 30687, 30599 and 30931)	30
71-10	Engine Assembly (s/n 30817, 30576, 30687, 30599 and 30931)	32
71-11	Engine Assembly (all s/n except 30817, 30576, 30687, 30599 and 30931)	34
71-12	Firewall Assembly, Forward and Fireshield Installation, Tail Rotor Driveshaft	36
71-13	Firewall Assembly, Aft, Upper and Lower (s/n 30178 thru sub)	40
71-14	Baffle Assembly, Induction	44
71-15	Bleed Air Installation, Turbo Blower and Cabin Heat	46
71-16	Engine Mount Installation	48
71-17	Engine Mount Detail	50
71-18	Throttle Lever Installation	52

CHAPTER 71 – POWER PLANT (71-00-00)




Figure 71-1 Cowl Installation



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-1				
1	MS21042L3	Nut	2	
2	NAS1197-10L	Washer	4	
3	AN315C3R	Nut	2	
4	205-060-830-001	U-Bolt	1	
5	205-060-805-049	Fairing Assembly, Transmission	1	
5	205-060-805-083	Fairing Assembly, Transmission (Alternate Part)	1	
6	AN525-832R7	Screw	6	
7	90-005-5	Latch	1	
8	MS21042L3	Nut	4	
9	NAS1197-10	Washer	4	
10	AN525-10R9	Screw	4	
11	NAS464P3A3	Bolt	4	
12	NAS1197-10	Washer	4	
13	205-060-814-001	Support Assembly, Forward Hinge, Engine Cowl	2	
14	75B6B5-5-4	Bushing	2	
15	MS20392-2S35	Pin	2	
16	NAS1149D0332J	Washer	2	
17	AN525-832R7	Screw	12	
18	90-029-1	Latch	2	
19	205-060-805-051	Fairing Assembly, Transmission	1	
19	205-060-805-085	Fairing Assembly, Transmission (Alternate Part)	1	
20	MS27980-7B	Stud	2	
21	MS27980-8B	Eyelet	2	
22	205-060-805-061	Seal	1	
23	205-060-805-057	Doubler	1	
24	205-060-805-059	Screen	1	
25	205-060-805-041	Seal	1	
26	205-060-805-039	Seal	1	
27	AN320-4	Nut	4	
28	NAS1197-416L	Washer	16	
29	NAS1149F0432P	Washer	8	
30	AN4-13	Bolt	2	
31	AN4-16	Bolt	2	
32	205-060-804-001	Hinge Assembly, Transmission Cowl, Forward	1	
33	205-060-372-003	Rod End	4	
34	AN316-7R	Nut	4	
35	205-060-804-003	Frame Assembly	1	
36	205-060-834-003	Plug	4	
37	MS21042L3	Nut	4	
38	NAS1149D0332J	Washer	4	
39	MS24694-S50	Screw	4	
40	205-060-870-001	Socket, LH	1	



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-1				
41	205-060-870-002	Socket, RH	1	
42	MS21042L3	Nut	4	
43	NAS1197-10	Washer	4	
44	AN3-4A	Bolt	10	
45	NAS1149D0332J	Washer	6	
46	205-060-871-007	Hinge Assembly, Engine Air Inlet Louver, LH	1	
47	205-060-871-008	Hinge Assembly, Engine Air Inlet Louver, RH	1	
48	MS20253P2-118	Pin	1	
49	205-060-871-009	Hinge Half, Upper, LH	1	
49	205-060-871-010	Hinge Half, Upper, RH	1	
50	205-060-871-011	Hinge Half, Lower, LH	1	
50	205-060-871-012	Hinge Half, Lower, RH	1	
51	205-060-865-003	Louver Assembly, Engine Air Inlet, LH	1	
52	205-060-865-004	Louver Assembly, Engine Air Inlet, RH	1	
53	40S5-11	Stud	2	
54	4002-0	Eyelet	2	
55	NAS1149F0832P	Washer (Note 1)	4	
56	50-037-1	Retainer	2	
57	205-060-869-001	Spring, LH	2	
57	205-060-869-002	Spring, RH	2	
58	205-060-864-001	Louver, LH	1	
58	205-060-864-002	Louver, RH	1	
59	AN3-3A	Bolt	8	
60	NAS1197-10	Washer	8	
61	205-060-872-002	Bracket	2	
61	D212-725-1-120	Bracket (Alternate Part)	2	
62	205-060-872-001	Bracket	2	
62	D212-725-1-119	Bracket (Alternate Part)	2	
63	205-060-873-001	Panel Assembly	1	
64	50-005A11	Stud	5	
65	GH5	Grommet	5	
66	50-005A11	Stud	5	
67	GH5	Grommet	5	
68	MS27980-7B	Stud	2	
69	MS27980-8B	Eyelet	2	
Note 1: Maximum quantity shown, refer to Eagle Single Maintenance Manual for specific fit.				



CHAPTER 71 – POWER PLANT (71-00-00)

This page intentionally left blank

CHAPTER 71 – POWER PLANT (71-00-00)




Figure 71-2 Cowl Installation

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •
THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-2				
1	205-060-801-015	Beam Assembly	1	
2	MS21042L3	Nut	4	
3	NAS1149D0332J	Washer	4	
4	AN525-10R8	Screw	4	
5	205-060-837-001	Fitting	2	
6	MS21042L3	Nut	12	
7	NAS1149D0332J	Washer	12	
8	AN525-10R6	Screw	12	
9	205-060-836-001	Fitting	3	
10	NAS1354DS7S29	Pin	2	
11	RS139-5	Chain Assembly	2	
12	MS21042L3	Nut	5	
13	NAS1149D0332J	Washer	5	
14	AN525-10R6	Screw	9	
15	205-060-883-001	Scoop	1	
17	205-060-801-017	Beam	1	

CHAPTER 71 – POWER PLANT (71-00-00)




Figure 71-3 Cowl Installation

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**

Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-3				
1	MS20392-2S31	Pin	2	
2	NAS1149D0332J	Washer	2	
3	MS21042L4	Nut	2	
4	NAS1149D0416J	Washer	4	
5	AN315C4R	Nut	2	
6	205-060-863-001	Fitting	2	
7	MS20392-2S17	Pin	6	
8	NAS1149D0332J	Washer	6	
9	205-060-807-083	Cowl Assembly, Engine, Upper, LH	1	
10	205-060-807-084	Cowl Assembly, Engine, Upper, RH	1	
11	MS21042L3	Nut	6	
12	NAS1149D0332J	Washer	6	
13	AN3-10A	Bolt	1	
14	AN3-7A	Bolt	1	
15	205-060-820-001	Hinge Assembly	3	
16	22-005B11-9-14	Bushing	2	
17	AN525-10R9	Screw	12	
18	205-060-818-001	Fitting	2	
19	205-060-818-002	Fitting	2	
20	205-060-819-001	Fitting	1	
21	205-060-819-002	Fitting	1	
22	MS20392-2S41	Pin	1	
23	NAS1149D0332J	Washer	9	
24	90-029-1	Latch	1	
25	AN525-10R9	Screw	4	
26	205-060-802-001	Brace Assembly	1	
27	MS20253P2-7200	Pin	1	
28	205-060-802-013	Fitting	2	
29	MS20392-2S19	Pin	1	
30	NAS1149C0332R	Washer	2	
31	NAS43DD3-8	Spacer	2	
32	205-060-802-011	Hinge	1	
33	205-060-802-003	Brace Assembly	1	
34	MS20392-1S17	Pin	1	
35	NAS1149CN416R	Washer	2	
36	205-060-802-007	Latch	1	
37	205-060-802-009	Spring	1	
38	MS20392-2S39	Pin	1	
39	NAS1149D0332J	Washer	1	
40	90-029-1	Latch	1	
41	205-060-807-082	Cowl Assembly, Air Intake, LH	1	
41	205-060-807-086	Cowl Assembly, Air Intake, RH	1	



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-3				
42	205-060-849-009	Scoop Assembly, Air Intake, LH	1	
42	205-060-849-010	Scoop Assembly, Air Intake, RH	1	
43	205-060-807-081	Seal	1	
44	205-060-807-013	Louver Assembly, LH	1	
44	205-060-807-014	Louver Assembly, RH	1	
45	205-060-807-015	Louver Assembly, LH	1	
45	205-060-807-016	Louver Assembly, RH	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

This page intentionally left blank

CHAPTER 71 – POWER PLANT (71-00-00)




Figure 71-4 Cowl Installation

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-4				
1	MS21042L3	Nut	8	
2	NAS1149D0332J	Washer	8	
3	AN3-6A	Bolt	8	
4	205-060-821-003	Fitting	2	
5	205-060-821-001	Fitting	2	
6	AN320-4	Nut	4	
7	NAS1149D0416J	Washer (Note 1)	4	
8	NAS1149F0432P	Washer (Note 1)	24	
9	NAS1149F0463P	Washer (Note 1)	16	
10	AN4-17	Bolt	4	
11	NAS1354D-S7S15	Pin	4	
12	NAS1455B00-(*)	Chain	4	
13	205-060-843-001	Hinge Assembly, Lower Engine Cowl, Upper	2	
14	205-060-843-003	Weld Assembly	1	
15	22-006B15-32-16	Bushing	4	
16	AN316-9R	Nut	2	
17	205-060-372-001	Rod End	2	
18	205-060-826-133	Cowl Assembly, Lower, LH	1	
19	205-060-826-134	Cowl Assembly, Lower, RH	1	
20	AN525-832R6	Screw	24	
21	NAS1149DN832J	Washer	24	
22	90-005-5	Latch	4	
23	AN525-10R10	Screw	8	
24	205-060-855-001	Support Hinge, LH	1	
24	205-060-855-002	Support Hinge, RH	1	
25	205-060-856-001	Support Hinge, LH	1	
25	205-060-856-002	Support Hinge, RH	1	
26	205-060-860-011	Support Assembly, LH	1	
26	205-060-860-012	Support Assembly, RH	1	
27	205-060-860-013	Support Assembly, LH	1	
27	205-060-860-014	Support Assembly, RH	1	
28	MS20253P2-250	Pin	2	
29	MS21042L06	Nut	1	
30	NAS1149DN632J	Washer	1	
31	P116-499-10-495	Stud	1	
32	AN525-10R8	Screw	3	
33	NAS1149D0332J	Washer	3	
34	205-060-862-001	Bracket Assembly	1	
35	50-031-1	Fastener	1	
36	MS20253P2-387	Pin	1	
37	204-060-887-001	Spring (Usable on 205-060-826-134)	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 1

Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-4				
38	205-060-826-015	Door Assembly (Usable on 205-060-826-134)	1	
39	90-015-064-091	Latch	1	
40	MS20253P2-538	Pin	1	
41	204-060-869-001	Spring	2	
42	205-060-826-011	Cowl Assembly, LH	1	
42	205-060-826-109	Cowl Assembly, RH	1	
43	205-060-826-013	Door Assembly, LH	1	
43	205-060-826-014	Door Assembly, RH (Usable on 205-060-826-012)	1	
43	205-060-826-115	Door Assembly, RH (Usable on 205-060-826-109)	1	
44	205-060-826-083	Gasket	1	
45	205-060-826-085	Gasket	1	
46	205-060-826-081	Seal	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

This page intentionally left blank

CHAPTER 71 – POWER PLANT (71-00-00)




Figure 71-5 Cowl Installation

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**

Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-5				
1	205-060-877-057	Fairing Assembly, Tail Pipe, Upper	1	
2	MS35206-245	Screw	3	
3	205-060-877-055	Plate	1	
4	205-060-877-075	Fairing Assembly	1	
5	50-005A17	Stud	4	
6	50-005A17	Stud	4	
7	50-005A20	Stud	2	
8	A5T25	Fastener	2	
9	GH5	Grommet	12	
10	205-060-877-043	Strip	2	
11	205-060-877-047	Strip	1	
12	205-060-803-001	Support	1	
13	205-060-877-035	Louver, LH	1	
14	205-060-877-036	Louver, RH	1	
15	205-060-877-037	Louver	1	
16	205-060-877-038	Louver	1	
17	205-060-877-039	Louver	1	
18	205-060-877-040	Louver	1	
19	205-060-877-041	Louver	1	
20	205-060-877-042	Louver	1	
21	205-060-877-043	Strip, Chafe	1	
22	205-060-810-039	Fairing Assembly, Tail Pipe, Lower, LH	1	
23	205-060-810-002	Fairing Assembly, Tail Pipe, Lower, RH	1	
24	50-005A17	Stud	3	
25	50-005A20	Stud	1	
26	GH5	Grommet	4	
27	50-008RF5	Receptacle	2	
28	205-060-810-033	Strip, Chafe	1	
29	205-060-810-035	Strip, Chafe	1	
30	AN523-2-600	Pin	1	
31	204-060-887-001	Spring	2	
32	205-060-810-015	Door Assembly, LH	1	
32	205-060-810-016	Door Assembly, RH	1	
33	H5000-032-064	Latch	1	
34	AN525-832R8	Screw (Usable on 205-060-810-002)	5	
35	205-060-810-031	Cover (Usable on 205-060-810-002)	1	
36	205-060-810-041	Fairing Assembly, LH	1	
36	205-060-810-004	Fairing Assembly, RH	1	
37	205-060-810-029	Retainer (Usable on 205-060-810-004)	1	
38	205-060-810-027	Seal (Usable on 205-060-810-004)	1	
39	205-060-881-001	Shield Assembly, Tail Pipe	1	
40	AN924-4	Nut	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**

Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-5				
41	NAS1149C0763R	Washer	1	
42	AN833-4	Elbow	1	
48	205-060-881-015	Gasket, LH	1	
49	205-060-881-021	Gasket, RH	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

This page intentionally left blank

CHAPTER 71 – POWER PLANT (71-00-00)




Figure 71-6 Power Plant Installation

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •
THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-6				
1	S4409-1950M	Coupling	1	
1	53418C1950M	Coupling (Alternate Part)	1	
2	204-060-133-001	Bolt	1	
3	NAS1149F0632P	Washer	1	
4	T53-17A	Engine Assembly	1	
4	T53-17B	Engine Assembly (Alternate Part)	1	
4	T53-17BCV	Engine Assembly (Alternate Part)		
5	205-060-205-117	Baffle Assembly, Induction (See Figure 71-12 thru 71-14 for breakdown)	1	
5	205-060-205-135	Baffle Assembly, Induction (See Figure 71-12 thru 71-14 for breakdown)	1	
6	AN4H3A	Bolt	3	
7	NAS1149F0432P	Washer	3	
8	AN4H3A	Bolt	1	
9	NAS1149F0432P	Washer	2	
10	831-0100	Detector Assembly, Ice	1	
11	MS51958-62	Screw	11	
12	AN525-10R9	Screw	18	
13	NAS1149F0332P	Washer	18	
14	205-060-908-095	Firewall Assembly, Forward (See Figure 71-12 thru 71-14 for breakdown)	1	
14	205-060-908-071	Firewall Assembly, Forward (See Figure 71-12 thru 71-14 for breakdown)	1	
14	205-060-908-131	Firewall Assembly, Forward (See Figure 71-12 thru 71-14 for breakdown)	1	
15	MS51958-62	Screw	12	
16	AN526C1032R12	Screw	4	
17	MS51958-64	Screw	7	
18	MS51958-63	Screw	24	
19	NAS1149CN632R	Washer	4	
20	NAS1149C0332R	Washer	4	
21	120-008C23E7	Shim	16	
22	205-060-907-061	Firewall Assembly, Lower Aft (See Figure 71-12 thru 71-14 for breakdown)	1	

CHAPTER 71 – POWER PLANT (71-00-00)




Figure 71-7 Engine Assembly



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-7				
1	19131-1812M	Clamp	1	
1	5218SS1812	Clamp (Alternate Part)	1	
2	19131-1537M	Clamp	1	
2	5218SS1537	Clamp (Alternate Part)	1	
3	204-060-302-013	Tailpipe Assembly	1	
4	205-060-909-025	Firewall Assembly (See Figure 71-12 thru 71-14 for breakdown)	1	
4	205-060-909-045	Firewall Assembly (See Figure 71-12 thru 71-14 for breakdown)	1	
6	AN6CH6A	Bolt	4	
7	NAS1149C0632R	Washer	4	
8	205-060-020-003	Bracket	1	
9	204-060-152-001	Fitting	1	
10	MS21043-6	Nut	1	
11	NAS1149C0663R	Washer	1	
12	204-061-100-001	Bearing	1	
13	AN3CH5A	Bolt	1	
14	AN320C3	Nut	1	
15	NAS1149C0363R	Washer	2	
16	NAS1003-10	Bolt	1	
17	204-060-765-007	Lever	1	
18	AN320C4	Nut	1	
19	NAS1149C0463R	Washer	1	
20	AN174-6	Bolt	1	
21	3539-14-02	Washer	1	
22	204-060-762-001	Actuator, Motor, Governor RPM	1	
23	AN8CH10A	Bolt	2	
24	AN8CH6A	Bolt	2	
25	NAS1149F0832P	Washer	4	
26	NAS1149F0863P	Washer	2	
27	205-060-020-007	Support	1	
28	204-060-161-001	Trunnion	1	
29	204-060-787-009	Cambox Assembly	1	
30	MS21042L3	Nut	1	
31	AN320-3	Nut	1	
32	NAS1149D0363J	Washer	4	
33	AN173-7A	Bolt	1	
34	AN173-15	Bolt	1	
35	204-060-786-001	Bracket	1	
36	120-008C11-7	Shim	4	
37	204-060-778-001	Housing	1	



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-7				
38	MS21042L3	Nut	3	
39	140-027-1D	Washer	1	
40	AN173-6A	Bolt	1	
41	NAS1149D0363J	Washer	1	
42	204-060-787-005	Cambox Assembly	1	
43	204-061-705-001	Cam	1	
44	204-060-779-001	Bellcrank	1	
45	MS27644-3	Bearing	1	
46	120-014-3A	Sleeve	1	
47	204-060-783-007	Slider Assembly	1	
48	204-060-782-001	Key	1	
49	204-060-785-001	Pin	1	
50	MS27641-3	Bearing	1	
51	MS35276-264	Screw	1	
52	204-060-729-001	Arm	1	
53	7G33-1	Switch	1	
54	22A554	Tach Generator, Power Turbine	1	
54	AG34	Tach Generator, Power Turbine (Alternate Part)	1	
54	32005-005	Tach Generator, Power Turbine (Alternate Part)	1	
54	2CM12AAA	Tach Generator, Power Turbine (Alternate Part)	1	
55	1103P217	Switch	2	
56	MS29512-04	Packing, Preformed	2	
57	AN814-4JL	Plug	2	
58	M83248/1-904	Packing, Preformed	2	
59	T5317-A/B/BCV	Engine	1	
60	MS21042L3	Nut	2	
61	NAS11490332J	Washer	2	
62	MS35207-262	Screw	2	
63	20-032-1	Bracket	6	



CHAPTER 71 – POWER PLANT (71-00-00)

This page intentionally left blank

CHAPTER 71 – POWER PLANT (71-00-00)




Figure 71-8 Engine Assembly (s/n 30817, 30576, 30687, 30599 and 30931)

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •
THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-8				
1	70-031C140-000	Hose Assembly	1	
2	70-031A150-000	Hose Assembly	1	
3	MS21042L3	Nut	1	
4	NAS1149D0332J	Washer	2	
5	MS35207-262	Screw	1	
6	20-032-1	Bracket	1	
7	MS21919WCH21	Clamp	1	
8	AN520-10R18	Screw	1	
9	NAS43DD3-40N	Spacer	1	
10	MS21919WCH21	Clamp	1	
11	AN4CH5A	Bolt	4	
12	NAS1149C0432R	Washer	4	
13	205-060-434-001	Adapter Assembly	1	
14	204-060-485-001	Gasket	1	
15	70-038F400-180	Hose Assembly	1	
16	204-060-084-001	Nut	1	
17	130-020-3	Transmitter, Oil Pressure	1	
18	MS21042L3	Nut	1	
19	NAS1149C0332R	Washer	1	
20	MS52958-63	Screw	1	
21	MS21919WCF11	Clamp	1	
22	8G1024	Switch, Engine Oil Pressure Warning	1	
23	205-061-042-001	Tube Assembly	1	
24	205-061-040-001	Bracket	1	
25	205-061-043-001	Tube Assembly	1	
26	AN924-4	Nut	2	
27	AN804J4	Tee	1	
28	204-060-031-015	Fitting Assembly	1	
29	MS29512-04	Packing, Preformed	2	
30	MS21042L3	Nut	2	
31	NAS1149F0332P	Washer	2	
32	AN525-10R6	Screw	2	
33	20-032-3	Bracket	2	
34	MS21919WCH4	Clamp	2	
35	AN737TW30	Clamp	1	
36	AN737TW56	Clamp	1	
37	205-061-531-009	Shroud	1	
38	205-061-531-015	Shroud	1	
39	205-061-046-001	Tube Assembly	1	
40	AN737TW56	Clamp	1	
41	205-061-531-015	Shroud	1	
42	156F001-5S-0146	Hose Assembly	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**

Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-8				
43	AN815-4	Union	1	
44	MS21042L3	Nut	3	
45	NAS1149D0332J	Washer	3	
46	MS35207-262	Screw	3	
47	MS21919WDG12	Clamp	6	
48	204-060-082-001	Tube Assembly	1	
49	AN919-2	Reducer	1	
50	MS29512-03	Packing, Preformed	1	
51	AN924-4	Nut	1	
52	AN834-4	Tee	1	
53	MS29512-04	Packing, Preformed	1	
54	70-009F060Z164A	Hose Assembly	1	
55	AN919-6	Reducer	2	
56	AN938J6	Tee	1	
57	MS29512-06	Packing, Preformed	2	
58	70-009F000X243A	Hose Assembly	1	
59	AN737TW58	Clamp	2	
60	205-061-531-005	Shroud	1	
61	205-061-531-007	Shroud	1	
62	624117-10D240	Hose Assembly	1	
63	70-009F000X174A	Hose Assembly	1	
64	110-033-1	Reducer	1	
65	M83248/1-903	Packing, Preformed	1	
66	AN737TW34	Clamp	1	
67	AN737TW56	Clamp	1	
68	205-061-531-001	Shroud	1	
69	205-061-531-029	Shroud	1	
70	110-640119L0264	Hose Assembly	1	
70	70-009L110C264A	Hose Assembly (Alternate Part)	1	
71	502383-10C	Elbow	1	
71	TA5221	Fitting (Alternate Part)	1	
72	M83248/1-910	Packing, Preformed	1	
73	MS51958-63	Screw	1	
74	NAS1149C0332R	Washer	1	
75	MS21042L3	Nut	1	
76	MS21919WCH9	Clamp	1	
77	205-061-061-001	Clip	1	
78	205-061-060-001	Heatshield	1	
79	AN3-3A	Bolt	4	
80	NAS1149D0332J	Washer	4	
81	205-061-062-001	Heatshield	1	
82	205-061-063-001	Clip	2	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 1

Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

This page intentionally left blank

CHAPTER 71 – POWER PLANT (71-00-00)





Figure 71-9 Engine Assembly (all s/n except 30817, 30576, 30687, 30599 and 30931)

[illegible]

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20

CHAPTER 71 – POWER PLANT (71-00-00)




Figure 71-10 Engine Assembly (s/n 30817, 30576, 30687, 30599 and 30931)

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**

Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-10				
1	AN6CH6A	Bolt	4	
2	NAS1149C0632R	Washer	4	
3	204-060-152-001	Fitting	1	
4	MS21043-6	Nut	1	
5	NAS1149C0663R	Washer	1	
6	204-061-100-001	Bearing	1	
7	205-061-045-001	Tube Assembly	1	
8	8G325	Switch, Engine Torque Pressure	1	
9	AN783J4	Tee	1	
10	204-060-068-001	Restrictor	1	
11	M83248/1-904	Packing, Preformed	3	
12	AN924-4	Nut	1	
13	205-061-044-001	Tube Assembly	1	
14	M83248/1-904	Packing, Preformed	2	
15	AN833-4	Elbow	2	
16	AN924-4	Nut	2	
17	204-060-084-001	Nut	1	
18	130-020-9	Transmitter	1	
19	AN8CH6A	Bolt	4	
20	NAS1149F0832P	Washer	4	
21	205-061-041-001	Bracket	1	
22	624139-12D146	Hose Assembly	1	
22	156F0003-12D0146	Hose Assembly (Alternate Part)	1	
23	AN815-12	Union	1	
24	624139-16D224	Hose Assembly	1	
24	156F0003-16D0224	Hose Assembly (Alternate Part)	1	
25	204-060-045-001	Fitting	1	
26	M83248/1-912	Packing, Preformed	2	
27	GEU-7/A	Tach Generator (Gas Producer)	1	
27	22A554	Tach Generator (Gas Producer) (Alternate Part)	1	
27	32005-007	Tach Generator (Gas Producer) (Alternate Part)	1	
27	AG34	Tach Generator (Gas Producer) (Alternate Part)	1	
27	32005-005	Tach Generator (Gas Producer) (Alternate Part)	1	
27	2CM12AAA	Indicator (Gas Producer)	1	
28	205-060-430-005	Generator Assembly, Starter	1	
33	204-060-200-001	Starter Generator	1	
34	20-032-1	Bracket	4	

CHAPTER 71 – POWER PLANT (71-00-00)




Figure 71-11 Engine Assembly (all s/n except 30817, 30576, 30687, 30599 and 30931)



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-11				
1	M83248/1-904	Packing, Preformed	1	
2	205-060-068-001	Fitting	1	
3	205-061-057-001	Tube Assembly	1	
4	AN783-4J	Fitting	1	
5	AN924-4J	Nut	1	
6	D212-725-1-227	Bracket	1	
7	AN924-4J	Nut	1	
8	AN938-4J	Fitting	1	
9	M83248/1-904	Packing, Preformed	1	
10	8G325	Transducer	1	
11	BAS-520-80G	Transducer	1	
12	M83248/1-904	Packing, Preformed	1	
13	M83248/1-904	Packing, Preformed	2	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20

CHAPTER 71 – POWER PLANT (71-00-00)




Figure 71-12 Firewall Assembly, Forward and Fireshield Installation, Tail Rotor Driveshaft

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**

Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-12				
1	AN525-10R9	Screw	9	
2	204-060-217-013	Screen Assembly	1	
2	205-060-206-101	Screen Assembly (Alternate Part)	1	
3	204-060-217-011	Screen Assembly	1	
4	50-007A15	Stud	4	
5	50-009-2	Grommet	4	
6	50-007A21	Stud	4	
7	50-009-2	Grommet	4	
8	204-060-217-009	Screen Assembly	1	
9	50-008RF2	Receptacle	4	
10	RF3 1-2 5	Receptacle	8	
11	205-060-210-001	Bellmouth Assembly, Engine Air	1	
11	205-060-210-003	Bellmouth Assembly, Engine Air	1	
12	50-008RF2	Receptacle	4	
13	205-060-209-001	Support (Usable on 205-060-210-001)	1	
14	205-060-210-015	Gasket	6	
15	MS21059L3	Nutplate	8	
16	AN525-10R9	Screw	18	
17	NAS1149C0332R	Washer	18	
18	204-060-815-071	Spacer	1	
19	204-060-868-001	Ring Assembly	1	
20	MS21059L3K	Nutplate	18	
21	MS21042L06	Nut	4	
22	NAS1149CN616R	Washer	4	
23	MS35275-227	Screw	4	
24	205-060-908-099	Cover	1	
25	205-060-908-097	Gasket	1	
26	MS21042L3	Nut	2	
27	NAS1149C0363R	Washer	2	
28	AN3-4A	Bolt	2	
29	205-060-910-001	Fitting	1	
30	205-060-753-001	Seal	1	
31	205-060-908-093	Firewall Assembly	1	
32	205-060-908-045	Gasket	2	
33	205-060-908-047	Seal	1	
34	205-060-908-043	Gasket	1	
35	50-008RF5	Receptacle	5	
36	50-008RF2	Receptacle	4	
37	D3648-041	Driveshaft Tunnel Assembly	1	
38	D3654-1	Doubler	1	
39	MS20427M4	Rivet	8	
40	AN3C-3A	Bolt	9	



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-12				
41	NAS1149C0363R	Washer	9	
42	D3682-1	Gasket	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

This page intentionally left blank

CHAPTER 71 – POWER PLANT (71-00-00)




Figure 71-13 Firewall Assembly, Aft, Upper and Lower

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**

Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)


Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-13				
1	MS21043-3	Nut	2	
2	NAS1149D0332J	Washer	2	
3	NAS1149C0332R	Washer	2	
4	AN3C4A	Bolt	2	
5	205-060-910-001	Fitting	1	
6	MS51958-63	Screw	15	
7	AN526C1032R12	Screw	1	
7	AN526C1032R14	Screw	1	
8	AN970-3	Washer	16	
9	205-060-909-029	Channel Assembly	1	
10	204-060-816-033	Gasket	1	
11	204-060-816-007	Channel	1	
12	NAS680-C3M	Nutplate	16	
12	NAS680-C3MK	Nutplate (Alternate Part)	16	
13	205-060-909-027	Firewall Assembly, Aft, Upper	1	
13	205-060-909-047	Firewall Assembly, Aft, Upper (Alternate Part)	1	
14	50-008RF5	Receptacle	4	
15	205-060-909-019	Doubler	4	
16	205-060-909-023	Gasket	1	
17	205-060-909-011	Retainer	1	
18	205-060-909-007	Seal	1	
19	99836	Pin	2	
20	294119-06	Washer	2	
21	98292-2-200	Stud	2	
22	205-060-909-017	Gasket	1	
23	99836	Pin	4	
24	294119-06	Washer	4	
25	98292-2-160	Stud	4	
26	204-060-816-033	Gasket	2	
27	204-060-809-003	Ring	1	
28	204-060-816-031	Ring	1	
29	MS21043-3	Nut	8	
30	204-060-927-001	Washer	8	
31	NAS1149C0363R	Washer	8	
32	MS24694-C55	Screw	8	
33	205-060-912-001	Fitting, LH	1	
34	205-060-912-002	Fitting, RH	1	
35	205-060-917-001	Plate	2	
36	MS21043-3	Nut	8	
37	NAS1149C0332R	Washer	8	
38	NAS1149C0363R	Washer	8	
39	204-060-927-001	Washer	8	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**

Date: 12.06.20

[illegible]

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

This page intentionally left blank

CHAPTER 71 – POWER PLANT (71-00-00)




Figure 71-14 Baffle Assembly, Induction

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •
THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-14				
1	205-060-205-113	Pan Assembly	1	
1	205-060-205-143	Pan Assembly (Alternate Part)	1	
2	50-009-2	Grommet	10	
3	50-008RF2	Receptacle	5	
4	50-007A18	Stud	2	
5	50-007A15	Stud	4	
6	50-007A12	Stud	4	
7	205-060-205-097	Gasket	1	
8	205-060-205-089	Gasket	2	
9	205-060-205-095	Gasket	2	
10	MS21042L3	Nut	1	
10A	MS27039-1-06	Screw	1	
11	204-060-224-003	Plug Installation	1	
12	204-060-224-009	Plate	1	
13	205-060-205-075	Baffle Assembly	1	
14	50-007A9	Stud	5	
15	50-007A18	Stud	4	
16	50-008RF2	Receptacle	8	
17	50-009-2	Grommet	9	
18	205-060-205-083	Gasket	2	
19	205-060-205-099	Gasket	2	
20	205-060-205-119	Baffle Assembly	1	
21	50-007A12	Stud	8	
22	50-007A18	Stud	2	
23	50-008RF5	Receptacle	5	
24	50-009-2	Grommet	10	
25	205-060-205-079	Gasket	2	

CHAPTER 71 – POWER PLANT (71-00-00)




Figure 71-15 Bleed Air Installation, Turbo Blower and Cabin Heat

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**

Date: 12.06.20



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-15				
1	AN815-16	Union	1	
1	110-153LM16J	Union (Alternate Part)	1	
2	3-916S613-60	Packing, Preformed	1	
9	3-908S613-60	Packing, Preformed	1	
13	U3290S2-175SS	Clamp	2	
14	M83248/1-216	Packing, Preformed	2	
15	205-060-439-001	Fitting	1	
15	205-060-439-003	Fitting (Alternate Part)	1	
16	205-060-421-001	Connector	1	
17	205-060-494-001	Fitting	1	
17	205-060-494-003	Fitting (Alternate Part)	1	
18	3-916S613-60	Packing, Preformed	1	
19	NAS1149F2132P	Washer (Note 1)	4	
20	AN815-12	Union	1	
20	110-153LM12J	Union (Alternate Part)	1	
21	3-912S613-60	Packing, Preformed	1	
22	205-060-424-001	Tube Assembly	1	
22	205-060-432-001	Tube Assembly (Alternate Part)	1	
23	AN837-12	Elbow	1	
23	110-157-12J	Elbow (Alternate Part)	1	
24	NAS1149F1732P	Washer (Note 1)	4	
25	AN924-12	Nut	1	
25	90-081LM12J	Nut (Alternate Part)	1	
26	140-009D69T109	Washer	1	
27	205-060-438-003	Gasket	2	
	Note 1: Maximum quantity shown. Minimum quantity of (1) at each location			

CHAPTER 71 – POWER PLANT (71-00-00)




Figure 71-16 Engine Mount Installation



CHAPTER 71 – POWER PLANT (71-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 71-16				
1	204-060-152-001	Main Trunnion	2	
2	204-061-100-001	Bearing (Alternate Part)	1	
3	204-060-151-001	Bearing Cap	2	
3	204-060-151-003	Bearing Cap (Alternate Part)	2	
4	204-060-102-009	Pillow Block Assembly	2	
4	204-060-102-011	Pillow Block Assembly (Alternate Part)	2	
5	AN24-19	Eye Bolt	1	
6	204-060-161-001	Forward Trunnion	1	
7	D3685-041	Bipod Mount Assembly	1	
8	NAS624-16	Bolt	1	
8	MS20002C4	Washer	1	
8	NAS1149F0432P	Washer	2	
8	MS21042L4	Nut	1	
9	NAS624-16	Bolt	1	
9	MS20002C4	Washer	1	
9	NAS1149F0463P	Washer	2	
9	MS21042L4	Nut	1	
10	204-060-133-001	Bolt	1	
10	NAS1149F0632P	Washer	1	
11	D3686-041	Monopod Assembly	1	
12	Engine Mount Deck Fittings (See IPC-D212-725 (53) Figure 53-2)			
13	NAS624-16	Bolt	1	
13	MS20002C4	Washer	1	
13	NAS1149F0463P	Washer	2	
13	MS21042L4	Nut	1	
14	NAS624-16	Bolt	1	
14	MS20002C4	Washer	1	
14	NAS1149F0463P	Washer	2	
14	MS21042L4	Nut	1	
15	NAS624-16	Bolt	1	
15	MS20002C4	Washer	1	
15	NAS1149F0463P	Washer	2	
15	MS21042L4	Nut	1	
16	NAS624-14	Bolt	1	
16	MS20002C4	Washer	1	
16	NAS1149F0463P	Washer	2	
16	MS21042L4	Nut	1	
17	D3684-041	Tripod Mount Assembly	1	

CHAPTER 71 – POWER PLANT (71-00-00)





Figure 71-17 Engine Mount Detail

[illegible]

1 – Used on D3684-041 Tripod Mount Assembly
2 – Used on D3685-041 Bipod Mount Assembly
3 – Used on D3686-041 Monopod Assembly

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20

CHAPTER 71 – POWER PLANT (71-00-00)





Figure 71-18 Throttle Lever Installation

[illegible]

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **1**
Date: 12.06.20



CHAPTER 76 – ENGINE CONTROLS (76-00-00)

CONTENTS – IPC
CHAPTER 76 ENGINE CONTROLS

Figure Number	Figure Title	Page Number
76-1	Controls Installation, Power Lever	2
76-2	Controls Installation, Power Lever	6
76-3	Controls Installation, Droop Compensator	10

CHAPTER 76 – ENGINE CONTROLS (76-00-00)




Figure 76-1 Controls Installation, Power Lever



CHAPTER 76 – ENGINE CONTROLS (76-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 76-1				
1	MS14145L3	Nut	1	
2	NAS1149D0363J	Washer	1	
3	AN173-10	Bolt	1	
4	204-061-717-003	Bearing	1	
5	212-060-724-017	Tube Assembly	1	
6	204-061-717-003	Bearing	1	
7	AN173-10	Bolt	1	
8	NAS1149D0332J	Washer	1	
9	MS14145L3	Nut	1	
10	AN173-10	Bolt	1	
11	NAS1149D0332J	Washer	1	
12	MS14145L3	Nut	1	
13	212-060-713-001	Bellcrank Assembly	1	
14	AN174-15	Bolt	1	
15	NAS1149D0463J	Washer	1	
16	MS14145L4	Nut	1	
17	204-061-717-003	Bearing	1	
18	AN737TW30	Clamp	1	
19	212-060-724-019	Tube Assembly	1	
20	204-061-717-003	Bearing	1	
21	AN173-10	Bolt	1	
22	NAS1149D0363J	Washer	1	
23	MS14145L3	Nut	1	
24	212-060-740-001	Bellcrank Assembly	1	
25	212-060-715-001	Mount	1	
25	212-060-715-103	Mount (Alternate Part)	1	
26	AN173-10	Bolt	1	
27	NAS1149D363J	Washer	1	
28	MS14145L3	Nut	1	
29	MS27039-1-09	Screw	6	
30	NAS1149D0332J	Washer	6	
31	MS21042L3	Nut	6	
32	D212-725-1-919	Tube Assembly	1	
33	AN173-12	Bolt	1	
34	NAS1149D0363J	Washer	1	
35	205-060-731-001	Washer	1	
36	NAS1149D0363J	Washer	1	
37	MS14145L3	Nut	1	
38	MS24665-152	Pin, Cotter	1	
39	205-060-766-001	Mount	1	
40	MS35207-264	Screw	3	
41	NAS1149D0363J	Washer	3	



CHAPTER 76 – ENGINE CONTROLS (76-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 76-1				
42	NAS1149C0432R	Washer	1	
43	AN970-4	Washer	1	
44	AN970-4	Washer	1	
45	NAS1149C0432R	Washer	1	
46	NAS1149D0463J	Washer	1	
47	MS14145L4	Nut	1	
48	MS24665-152	Pin, Cotter	1	
49	AN173-11	Bolt	1	
50	NAS1149D0363J	Washer	2	
51	NAS1149D0363J	Washer	1	
52	MS14145L3	Nut	1	
53	MS24665-152	Pin, Cotter	1	
54	205-060-729-023	Rod Assembly	1	
55	AN173-12	Bolt	1	
56	NAS1149D0363J	Washer	2	
57	205-060-720-001	Bellcrank Assembly	1	
58	NAS1149D0363J	Washer	2	
59	NAS1149D0363J	Washer	1	
60	MS14145L3	Nut	1	
61	MS24665-152	Pin, Cotter	1	
62	205-060-766-001	Mount	1	
63	MS35207-264	Screw	3	
64	NAS1149D0363J	Washer	3	
65	NAS1149C0432R	Washer	1	
66	AN970-4	Washer	1	
67	AN970-4	Washer	1	
68	NAS1149C0432R	Washer	1	
69	NAS1149D0463J	Washer	1	
70	MS14145L4	Nut	1	
71	MS24665-152	Pin, Cotter	1	
72	AN173-12	Bolt	1	
73	NAS1149D0363J	Washer	2	
74	NAS1149D0363J	Washer	2	
75	NAS1149D0363J	Washer	1	
76	MS14145L3	Nut	1	
77	MS24665-152	Pin, Cotter	1	
78	MS27640-4	Bearing	1	
78	120-011-4A	Sleeve	1	
79	205-060-719-001	Bellcrank	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0

Date: 11.06.06



CHAPTER 76 – ENGINE CONTROLS (76-00-00)

This page intentionally left blank

CHAPTER 76 – ENGINE CONTROLS (76-00-00)




Figure 76-2 Controls Installation, Power Lever



CHAPTER 76 – ENGINE CONTROLS (76-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 76-2				
1	MS24665-152	Pin, Cotter	2	
2	MS14145L3	Nut	2	
3	NAS1149D0363J	Washer	4	
4	AN173-12	Bolt	2	
5	205-060-729-025	Rod Assembly	1	
6	AN3-7A	Bolt	2	
7	204-060-796-001	Washer	2	
8	204-060-795-005	Cam	1	
9	MS24665-152	Pin, Cotter	1	
10	MS14145L4	Nut	1	
11	NAS1149D0463J	Washer	1	
12	NAS1149C0432R	Washer	2	
13	AN970-4	Washer	2	
14	205-060-721-001	Bellcrank Assembly	1	
15	MS27640-4	Bearing	1	
16	120-011-4A	Sleeve	1	
16A	MS21073L3	Nutplate	2	
17	MS35207-263	Screw	3	
18	NAS1149D0363J	Washer	3	
19	205-060-766-001	Mount	1	
20	AN3-5A	Bolt	4	
21	NAS1149D0332J	Washer	4	
22	204-060-797-005	Bracket (Note 1)	1	
23	22-007B20-12-18	Bushing	1	
24	205-060-772-001	Base	1	
25	MS24693-C270	Screw	4	
26	120-031-12-7	Shim (Note 1)	4	
27	209-062-761-001	Valve, Solenoid	1	
28	AN3-3A	Bolt	5	
29	NAS1149F0332P	Washer	5	
30	MS24665-152	Pin, Cotter	2	
31	MS14145L3	Nut	2	
32	NAS1149F0363P	Washer	4	
33	AN173-11	Bolt	2	
34	MS24665-152	Pin, Cotter	1	
35	MS14145L4	Nut	1	
36	NAS1149F0432P	Washer	1	
37	50Z16-9-2	Spacer	1	
38	AN174-24	Bolt	1	
39	204-060-743-005	Lever	1	
40	MS27644-4	Bearing	1	
41	AN737TW82	Clamp	2	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0

Date: 11.06.06



CHAPTER 76 – ENGINE CONTROLS (76-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 76-2				
42	MS16624-1081	Retainer	1	
43	204-060-767-001	Retainer	1	
44	204-060-769-001	Bushing	1	
45	205-060-732-001	Boot Assembly	1	
46	D212-725-1-929	Housing Assembly	1	
47	205-060-734-011	Rod Assembly	1	
48	MS24665-152	Pin, Cotter	1	
49	AN320C3	Nut	1	
50	NAS1149C0332R	Washer	1	
51	NAS1003-10	Bolt	1	
52	205-060-733-009	Rod Assembly	1	
53	AN316-4R	Nut	1	
54	MS21153-1	Bearing	1	
	Note 1: 120-031-12-7 shim are not required when 204-060-797-005 Bracket Assembly is used			

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0
Date: 11.06.06



CHAPTER 76 – ENGINE CONTROLS (76-00-00)

This page intentionally left blank

CHAPTER 76 – ENGINE CONTROLS (76-00-00)




Figure 76-3 Controls Installation, Droop Compensator



CHAPTER 76 – ENGINE CONTROLS (76-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 76-3				
1	MS24665-152	Pin, Cotter	2	
2	AN310-3	Nut	2	
3	NAS1149D0332J	Washer	2	
4	NAS1149F0332P	Washer	2	
5	AN173-10	Bolt	1	
6	NAS1149D0363J	Washer	4	
7	AN173-12	Bolt	1	
8	205-060-702-001	Tube Assembly	1	
9	AN316-5R	Nut	1	
10	MS21153-2	Bearing	1	
11	MS21042L3	Nut	2	
12	NAS1149C0363R	Washer	2	
13	AN173-10A	Bolt	2	
14	MS21042L4	Nut	1	
15	NAS1149F0463P	Washer	2	
16	204-060-750-001	Washer	1	
17	204-060-751-001	Shim	2	
18	204-060-752-005	Pin	1	
19	205-060-752-001	Fitting	1	
20	205-060-751-003	Bellcrank	1	
21	MS21042L3	Nut	3	
22	NAS1149D0332J	Washer	6	
23	MS27039-1-10	Screw	3	
24	205-060-716-001	Bracket Assembly	1	
25	MS20218-1	Bearing	1	
26	MS24665-152	Pin, Cotter	1	
27	AN310-3	Nut	1	
28	NAS1149D0332J	Washer	2	
29	AN173-11	Bolt	1	
30	205-060-710-001	Jackshaft Assembly	1	
31	205-060-754-001	Bellcrank	1	
32	MS35207-261	Screw	4	
33	NAS1149F0332P	Washer	4	
34	205-060-715-001	Support Assembly	1	
35	MS20218-1	Bearing	1	
36	MS24665-152	Pin, Cotter	1	
37	AN310-3	Nut	1	
38	NAS1149D0332J	Washer	2	
39	AN173-11	Bolt	1	
40	205-060-712-001	Rod Assembly	1	
41	AN316-4R	Nut	1	
42	MS21153-1	Bearing	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0

Date: 11.06.06

CHAPTER 79 – ENGINE OIL SYSTEM (79-00-00)




Figure 79-1 Engine Oil System Installation



CHAPTER 79 – ENGINE OIL SYSTEM (79-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 79-1				
1	AN833-12J	Elbow	1	
2	AN924-12	Nut	1	
3	M83248/1-912	Packing, Preformed	1	
4	AN815-12	Union	2	
5	M83248/1-912	Packing, Preformed	2	
6	AN815-16	Union	1	
7	M83248/1-916	Packing, Preformed	1	
8	AN815-6	Union	1	
9	465C62NSV	Valve	1	
10	AN924-6	Nut	1	
11	M83248/1-906	Packing, Preformed	2	
12	NAS27-3-22	Turnbuckle	2	
13	MS21042L3	Nut	8	
14	NAS1149D0332J	Washer	8	
15	AN3-10A	Bolt	8	
16	205-061-521-001	Block	4	
17	205-061-520-015	Support Assembly	1	
18	205-061-520-017	Support Assembly	1	
19	205-061-520-013	Pad	2	
20	NAS25-3L	Trunnion	2	
21	NAS25-3R	Trunnion	2	
22	MS27833-8-183	Pad	2	
23	205-060-538-079	Tank Assembly, Engine Oil	1	
24	205-061-530-001	Cap Assembly	1	
25	205-061-529-001	Dipstick	1	
26	417-290	Adapter	1	
27	NAS617-28	Packing, Preformed	1	
28	S20	Plug	1	
29	M83248/1-916	Packing, Preformed	1	
30	S21	Plug	1	
31	NAS617-28	Packing, Preformed	1	
32	AN806S16	Plug	1	
33	M83248/1-916	Packing, Preformed	1	
34	205-060-538-071	Tank Assembly	1	
35	204-060-528-001	Nameplate	1	

CHAPTER 79 – ENGINE OIL SYSTEM (79-00-00)




Figure 79-2 Oil System Installation



CHAPTER 79 – ENGINE OIL SYSTEM (79-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 79-2				
1	MS21042L3	Nut	1	
2	NAS1149D0332J	Washer	2	
3	MS27039-1-15	Screw	1	
4	MS21919WDG12	Clamp	1	
5	205-060-575-001	Tube Assembly	1	
6	205-060-594-001	Tube Assembly	1	
7	AN924-12D	Nut	2	
8	NAS1149D1790J	Washer	4	
9	AN833-12J	Elbow	1	
10	AN837-12	Elbow	1	
11	MS21042L3	Nut	1	
12	NAS1149D0332J	Washer	2	
13	NAS43DD3-64	Spacer	1	
14	MS27039-1-29	Screw	1	
15	MS21919WDG6	Clamp	1	
16	MS21042L3	Nut	1	
17	NAS1149C0332R	Washer	2	
18	MS27039-1-08	Screw	2	
19	20-032-1	Bracket	1	
20	MS21919WDG6	Clamp	1	
21	205-060-593-001	Tube Assembly	1	
22	205-060-592-001	Tube Assembly	1	
23	205-060-591-001	Tube Assembly	1	
24	AN824-6J	Tee	1	

CHAPTER 79 – ENGINE OIL SYSTEM (79-00-00)




Figure 79-3 Oil System Installation



CHAPTER 79 – ENGINE OIL SYSTEM (79-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 79-3				
6	NAS1149D0332J	Washer	2	
7	AN525-10R8	Screw	2	
8	MS21919WDG6	Clamp	2	
9	MS21919WDG12	Clamp	2	
10	MS21042L3	Nut	1	
11	NAS1149D0332J	Washer	1	
12	AN525-10R8	Screw	1	
13	MS21919WDG6	Clamp	1	
14	MS21919WDG12	Clamp	1	
15	MS21042L3	Nut	1	
16	NAS1149D0332J	Washer	1	
17	AN525-10R7	Screw	1	
18	MS21919WDG6	Clamp	1	
19	MS21919WDG12	Clamp	1	
20	AN833-6	Elbow	1	
21	AN924-6D	Nut	1	
22	NAS1149D0963J	Washer	1	
23	205-060-581-001	Tube Assembly	1	
24	D212-725-1-935	Tube Assembly	1	
25	MS21042L3	Nut	2	
26	NAS1149D0332J	Washer	2	
27	AN525-10R8	Screw	2	
28	MS21919WDG10	Clamp	3	
29	MS21919WDG12	Clamp	1	
30	205-061-507-001	Tube Assembly	1	
31	AN919-20D	Reducer	1	
32	205-061-505-001	Tube Assembly	1	
32	205-061-532-001	Tube Assembly (Alternate Part)	1	
33	205-061-523-001	Tube Assembly	1	
33	D212-725-1-921	Tube Assembly (Alternate Part)	1	
33	156F003-12S0240	Hose Assembly (Alternate Part)	1	
34	AN737TW38	Clamp	2	
35	205-061-531-017	Shroud	2	
36	AN919-20J	Reducer	1	
37	M83248/1-910	Packing, Preformed	1	
38	AN832-12	Union	1	
39	AN924-12D	Nut	1	
40	NAS1149D1790J	Washer	1	
41	AN525-10R8	Screw	1	
42	NAS1149D0332J	Washer	1	
43	MS21919WDG10	Clamp	1	
44	205-060-585-001	Tube Assembly	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0

Date: 11.06.06



CHAPTER 79 – ENGINE OIL SYSTEM (79-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 79-3				
45	AN919-20D	Reducer	1	
46	AN525-10R8	Screw	1	
47	NAS1149D0332J	Washer	1	
48	MS21919WDG10	Clamp	1	
49	MS21042L3	Nut	1	
50	NAS1149D0332J	Washer	1	
51	AN525-10R7	Screw	1	
52	MS21919WDG10	Clamp	1	
53	MS21919WDG4	Clamp	1	
54	205-061-526-001	Tube Assembly	1	
54	205-061-533-001	Tube Assembly (Alternate Part)	1	
55	205-061-524-001	Tube Assembly	1	
56	212-040-232-001	Valve	1	
57	AN924-6	Nut	1	
58	M83248/1-906	Packing, Preformed	1	
59	AN833-6	Elbow	1	
60	AN924-6D	Nut	1	
61	NAS1149D0963J	Washer	2	
62	AN525-10R8	Screw	2	
63	NAS1149D0332J	Washer	2	
64	MS21919WDG4	Clamp	2	
65	MS21919WDG6	Clamp	2	
66	AN525-10R8	Screw	2	
67	NAS1149D0332J	Washer	2	
68	MS21919WDG6	Clamp	4	
69	205-060-583-001	Tube Assembly	1	
70	205-061-527-001	Tube Assembly	1	
71	AN832-4	Union	1	
72	AN924-4D	Nut	1	
73	NAS1149D0763J	Washer	1	
74	AN832-4	Union	1	
75	NAS1149D0763J	Washer	1	
76	AN924-4	Nut	1	
77	MS21042L3	Nut	2	
78	NAS1149D0332J	Washer	2	
79	AN525-10R7	Screw	1	
80	AN525-10R18	Screw	1	
81	AN743-12	Bracket	1	
82	MS21919WDG6	Clamp	1	
83	205-061-528-001	Tube Assembly	1	
84	MS35489-6	Grommet	1	
85	MS35489-11	Grommet	3	
86	MS35489-135	Grommet	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0
Date: 11.06.06



CHAPTER 79 – ENGINE OIL SYSTEM (79-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 79-3				
87	70-037B152-000	Hose Assembly	1	
88	204-060-494-011	Fitting	1	
89	3-916S613-60	Packing, Preformed	1	
90	AE5023379	Fitting	4	
91	MS21042L3	Nut	16	
92	204-060-184-001	Gasket	4	
93	AN814-6WL	Plug	4	
94	M83248/1-906	Packing, Preformed	4	
95	AN938D10	Tee	2	
96	AN783D10	Tee	2	
97	AN939D10	Elbow	2	
98	AN815-10D	Union	2	
99	MS9015-10	Plug	4	
100	M83248/1-910	Packing, Preformed	12	
101	AN924-10D	Nut	6	
102	204-060-567-001	Fitting	4	
103	AN919-20J	Reducer	1	
104	M83248/1-910	Packing, Preformed	1	
105	AN814-4J	Plug	1	
106	M83248/1-904	Packing, Preformed	1	
107	MS21042L4	Nut	4	
108	NAS1149D0463J	Washer	4	
109	AN4-6A	Bolt	4	
110	225126	Filter Assembly	1	
111	137287	Filter Element	1	
112	200L4-275-5	T-Bolt	1	
113	N4309S5-350	Clamp Assembly	1	
114	AN3-3A	Bolt	4	
115	NAS1149D0363J	Washer	4	
116	205-061-522-001	Bracket	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0
Date: 11.06.06

CHAPTER 79 – ENGINE OIL SYSTEM (79-00-00)




Figure 79-4 Oil System Installation



CHAPTER 79 – ENGINE OIL SYSTEM (79-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 79-4				
1	MS21042L4	Nut	4	
2	MS35489-6	Grommet	8	
3	NAS1149D0463J	Washer	12	
4	AN4-12A	Bolt	4	
5	204-060-592-001	Screen	1	
6	AN3H5A	Bolt	3	
7	NAS1149D0332J	Washer	3	
8	AN3-3A	Bolt	8	
9	NAS1149D0332J	Washer	8	
10	204-062-540-001	Turbine Fan Assembly, Engine Oil Cooling	1	
11	AN3-4A	Bolt	26	
12	NAS1149D0332J	Washer	26	
13	205-061-502-001	Duct Assembly	1	
14	205-061-503-001	Support Assembly	1	
15	MS21042L5	Nut	4	
16	NAS1149D0563J	Washer	4	
17	AN5-7A	Bolt	4	
18	NAS1149D0516J	Washer	4	
19	AN4-4A	Bolt	1	
20	AN4-6A	Bolt	1	
21	NAS1149D0416J	Washer	2	
22	205-061-538-003	Support Assembly, LH	1	
23	MS21073L4	Nutplate	1	
24	MS21071L4	Nutplate	1	
25	AN4-4A	Bolt	2	
26	NAS1149D0416J	Washer	2	
27	205-061-538-001	Support Assembly, RH	1	
28	MS21069L4	Nutplate	2	
29	209-060-522-003	Oil Cooler, Oil, Transmission	1	
30	209-060-522-001	Cooler Assembly, Oil, Engine	1	

CHAPTER 79 – ENGINE OIL SYSTEM (79-00-00)




Figure 79-5 Turbine Fan Assembly, Engine Oil Cooling




CHAPTER 79 – ENGINE OIL SYSTEM (79-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 79-5				
1	MS20365-428A	Nut	8	
2	NAS1149F0463P	Washer	8	
3	AN4-7A	Bolt	8	
4	132105-2	Turbine and Fan Assembly	1	
5	MS21044N7	Nut	1	
6	NAS1149F0763P	Washer	1	
7	R3466-5	Fan and Turbine Assembly	1	
8	MS35266-64	Screw	4	
9	R3648-1	Retainer	1	
10	MS35756-6	Key	1	
11	9103PP	Bearing	1	
12	MS21044N5	Nut	1	
13	R2607-1	Washer	1	
14	H33C32	Bearing	1	
15	R3467-1	Shaft	1	
16	158051-1	Plate	1	
17	R3393-4	Housing Assembly	1	
18	1191-3CNX570	Insert	4	
19	R3699-1	Housing Assembly	1	

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: 0
Date: 11.06.06



CONTENTS – IPC

CHAPTER 95 INSTRUMENTS

[illegible]

CHAPTER 95 – INSTRUMENTS (95-00-00)




Figure 95-1 Instrument Panel Assembly (Sheet 1 of 3)
(S/N's 30687, 30817 and 30599)

CHAPTER 95 – INSTRUMENTS (95-00-00)




Figure 95-1 Instrument Panel Assembly (Sheet 2 of 3)
(S/N's 30687, 30817 and 30599)

CHAPTER 95 – INSTRUMENTS (95-00-00)




Figure 95-1 Instrument Panel Assembly (Sheet 3 of 3)
(S/N's 30687, 30817 and 30599)

CHAPTER 95 – INSTRUMENTS (95-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 95-1				
1	204-070-483-001	Air Vent	4	
2	5A58.22.18K.28.1.HN	Airspeed Indicator	2	
3	RCA2600-3	Attitude Indicator	2	
4	LED-40-17-HK-35396	AY1 Master Caution (Yellow)	2	
5	LED-40-17-HK-35397	AR1 Engine, RPM (Red)	2	
6	LED-40-17-HK-36154	AR1 Rotor RPM (Yellow)	2	
7	LED-40-17-HK-35399	AR1 Baggage Fire (Red)	2	
8	LED-40-17-HK-35400	AY1 Cargo Release Armed Light (Red)	2	
9	01-0770119-12	Post Light	8	
10	15035-01102	Altimeter	2	
11	205-075-170-001	Torque Indicator	2	
11	205-070-043-001	Glass	2	
12	204-072-129-005	Dual Tach Indicator	2	
13	811B-24	Clock	2	
14	LED-40-17-EJ-36155	Heater Light	1	
15	MS25089-3C	Baggage Fire Test Switch	1	
16	209-070-280-101	Handle Fire 1	1	
17	204-075-815-003	Guard	1	
17	MS24523-30	Switch	1	
18	W103P3	Fire Test Switch	3	
19	Part of ELT-100HM Kit	ELT Test Switch	1	
20	D212-725-7-017	Master Caution Panel	1	
21	MS25089-3C	Fuel Quantity Test Switch	1	
22	MS25025-1	Loadmeter	1	
23	D212-725-7-001	Fuel Quantity Indicator	1	
24	D212-725-7-003	Gas Producer Tach Indicator	1	
25	D212-725-7-005	Fuel Pressure Indicator	1	
26	61000-092	EGT/MGT Indicator	1	
27	D212-725-7-009	Transmission Oil Temperature/Pressure Indicator	1	
28	D212-725-7-011	Engine Oil Temperature/Pressure Indicator	1	
29	D212-725-7-013	Hydraulic Oil Temperature/Pressure Indicator	1	
30	D212-725-7-015	Dual Voltage Indicator	1	
31	5550-8340N5L	Turn and Bank Indicator	1	
32	RCA15BK-1	Directional Gyro	1	
33	35060-1106	Instantaneous Vertical Speed Indicator	1	
34	D212-725-1-019	Instrument Panel, LH	1	
35	D212-725-1-021	Instrument Panel, Center	1	
36	D212-725-6-003	Placard	1	
37	D212-725-6-001	Placard	1	
38	D212-725-1-023	Instrument Panel, RH	1	

CHAPTER 95 – INSTRUMENTS (95-00-00)




Figure 95-2 Instrument Panel Assembly (Sheet 1 of 3)
(All S/N's except 30687, 30817, and 30599)

[illegible]

Figure 95-2 Instrument Panel Assembly (Sheet 2 of 3)
(All S/N's except 30687, 30817, and 30599)

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **3**
Date: 23.09.01

CHAPTER 95 – INSTRUMENTS (95-00-00)




Figure 95-2 Instrument Panel Assembly (Sheet 3 of 3)
(All S/N's except 30687, 30817, and 30599)

CHAPTER 95 – INSTRUMENTS (95-00-00)

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 95-2				
1	204-070-483-001	Air Vent	4	
2	811B-24	Clock	2	
3	5A58.22.18K.28.1.HN	Airspeed Indicator	2	
4	RCA2600-3	Attitude Indicator	2	
5	15035-01102	Altimeter	2	
5	5237A-A.906	Altimeter (Alternate Part)	2	
6	LED-44-14-HK-38632	Engine Fire Switch Light	2	
7	LED-40-11-HK-35396	Master Caution Light	2	
8	LED-43-11-HK-38633	Fire Extinguisher Switch Light	2	
9	LED-40-17-HK-36154	Rotor RPM Light (Yellow)	2	
10	LED-40-17-HK-35397	Engine RPM Light (Red)	2	
11	LED-40-17-HK-35399	Cargo Fire Light (Red)	2	
12	LED-40-17-HK-35400	Cargo Release Armed Light (Red)	2	
13	65100-068	Torque Pressure Indicator	2	
13	65100-057	Torque Pressure Indicator	2	1
14	64200-003	Dual Tach Indicator	2	
15	D212-725-7-017	Master Caution Panel	1	
16	W103P3	Fire Test Switch	3	
17	MS25089-3C	Cargo Fire Switch	1	
18	Part of ELT-100HM Kit	ELT Test Switch	1	
19	01-0770119-14	Heater Light	1	
20	LED-40-17-EJ-36155	Heater Switch	1	
21	Part of Inlet Filter Kit	Filter Bypass Switch Light (per SH07-49)	1	
22	MS25089-3C	Fuel Quantity Test Switch	1	
23	393008-047	Fuel Quantity Indicator	1	
24	64000-026	Gas Producer Tach Indicator	1	
25	411-10037	Fuel Pressure Indicator	1	
26	61000-092	MGT Indicator	1	
27	65000-018	Transmission Oil Temperature/Pressure Indicator	1	
28	65000-031	Engine Oil Temperature/Pressure Indicator	1	
29	65000-030	Hydraulic Oil Temperature/Pressure Indicator	2	
30	711-10022	Voltmeter/Ammeter	1	
31	RCA15BK-1	Directional Gyro Indicator	1	
32	35060-1106	Instantaneous Vertical Speed Indicator	1	
32	4A58.22.60F.28.1.BH	Instantaneous Vertical Speed Indicator (Alternate Part)	1	
33	5550-8340N5L	Turn and Bank Indicator	1	
34	D212-725-1-205	Instrument Panel, LH	1	
35	D212-725-6-003	Placard	1	

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **3**

Date: 23.09.01



CHAPTER 95 – INSTRUMENTS (95-00-00)

Item Number	Part Number	Item Name	Unit per Assy	UOC
36	D212-725-1-207	Instrument Panel, Center	1	
37	D212-725-1-209	Instrument Panel, RH	1	
38	D212-725-6-001	Placard	1	


UOC Code

1 – With TBN-212-003 incorporated

• COPYRIGHT © 2023 BY EAGLE COPTERS MAINTENANCE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **3**
Date: 23.09.01



CONTENTS – IPC

CHAPTER 96 ELECTRICAL SYSTEM

Use D212-725-8/-8-G2 for all other electrical parts.

CHAPTER 96 – ELECTRICAL SYSTEM (96-00-00)




Figure 96-1 Position and Strobe Lights

Item Number	Part Number	Item Name	Unit per Assy.	UOC
Figure 96-1				
1	01-0770875-02	Light, Upper Position, LH	1	
1	01-0770875-01	Light, Upper Position, RH	1	
2	01-0770905-01	Light, Upper Strobe	1	
3	01-0771011-02	Light, Tail Navigation	2	
4	01-0770875-02	Light, Lower Position, LH	1	
4	01-0770875-01	Light, Lower Position, RH	1	
5	01-0770905-01	Light, Lower Strobe	1	



CHAPTER 97 – AVIONICS (97-00-00)

CHAPTER 97 AVIONICS (97-00-00)

REFER TO BHT-212-IPC

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: **0**
Date: 11.06.06