EAGLE

EAGLE COPTERS LTD. · CALGARY, CANADA

EPCS

EAGLE PART & COMPONENT SOLUTIONS

ROTORCRAFT PARTS & COMPONENTS

EXTENDED PARTS AVAILABLE NOW

Gearboxes, rotor components, airframe structures and avionics in stock.

PART DESCRIPTION	PART NUMBER
T/R Gearbox	406-040-400-121FM
Tail Boom	212-030-100-163FM
Mast Assy	407-040-038-123A
Emergency Float	412-706-004-163

PART DESCRIPTION	PART NUMBER
Engine Inlet Air Filter	1076T-1
Swashplate & Support	412-010-402-115
Nav Computer, UNS-1F	2192-30-111100
Dual Hydraulic Kit	205-DUAL KIT

For Availability & Pricing, please contact partsales@eaglecopters.com

EAGLE COPTERS LTD. · CALGARY, CANADA

EPCS
EAGLE PART & COMPONENT SOLUTIONS

EXTENDED PARTS INVENTORY

FEATURED COMPONENTS

PART DESCRIPTION	PART NUMBER	CATEGORY
T/R Gearbox	406-040-400-121FM	Drive train
Tail Boom	212-030-100-163FM	Airframe
Control Rod Assembly	7001484-901	Flight controls
Emergency Float	412-706-004-163	Safety
Mast Assy	407-040-038-123A	Rotor
Engine Inlet Air Filter System	1076T-1	Engine
Spider Assy	204-040-397-001	Rotor
Elevator Assy	205-030-856-131	Airframe
Symbol Generator	7011672-781	Avionics
Rate Gyro	214-075-244-001	Avionics
Passenger Door Assy, RH	205-032-669-262	Airframe
Swashplate & Support Assy	412-010-402-115	Rotor
Hydraulic Actuator	212-076-004-103	Hydraulics
Dual Hydraulic Kit	205-DUAL KIT	Hydraulics
Mid Float with Liferaft, RH	614.5702	Safety
Nav Computer Unit, UNS-1F	2192-30-111100	Avionics
Freewheeling Assy	406-040-500-131FM	Drive train
Fuel Cell Assy	412-060-603-103	Fuel system

For Availability & Pricing, please contact partsales@eaglecopters.com

AIRFRAME & INTERIOR

PART NUMBER	PART DESCRIPTION
1-030-400-01	SUPPORT
204-030-062-003	PANEL ASSY
204-030-291-016	CAP ASSY
204-030-772-039	PANEL ASSY
204-031-154-027	PANEL ASSY
204-031-178-005	PANEL ASSY
204-031-277-005	PANEL ASSY
204-031-468-102P	HINGE HALF
204-032-841-007	PANEL
205-030-169-251	PANEL
205-030-173-032	PANEL ASSY
205-030-173-037	FLOOR ASSY
205-030-280-157	DECK ASSY
205-030-396-011	PANEL
205-030-403-067	PANEL ASSY, CENTER BULKHEAD
205-030-407-286	PANEL ASSY
205-030-407-497A	PANEL ASSY
205-030-782-103S	BULKHEAD ASSY
205-030-856-093A	ELEVATOR R/H
205-030-856-131	ELEVATOR ASSY
205-030-856-157	L/H ELEVATOR ASSEMBLY
205-030-856-159	ELEVATOR ASSY
205-030-953-025	DOOR ASSY
205-031-197-099	PANEL ASSY
205-031-235-017	PANEL ASSY
205-031-257-003	FL PANEL ASSY
205-031-257-050	FL PANEL ASSY
205-031-326-003	DOOR ASSY
205-032-101-007	CABIN ROOF PANEL ASSEMBLY
205-032-147-027	FLOOR PNL ASSY
205-032-669-262	DOOR ASSY, PASSANGER, RH
205-032-806-019S	LONGERON/LOWER
205-032-809-105	PANEL ASSY
205-032-814-007	PANEL ASSY

PART NUMBER	PART DESCRIPTION
205-032-815-037	PANEL ASSEMBLY
205-032-818-005	FWD BULKHEAD PANEL TAILBOOM
205-032-819-009	PANEL, ASSY
205-070-496-001	DUCT ASSY
212-030-009-097S	DECK ASSEMBLY
212-030-010-159	R/H ROOF ASSEMBLY
212-030-100-163FM	TAIL BOOM
212-030-276-001	PANEL ASSY
212-030-464-001	WINDSHIELD
212-060-801-001	PYLON FAIRING ASSY.
212-060-901-163	L/H FIREWALL
407-030-713-103	BAGGAGE FLOOR PANEL
412-030-326-101	PANEL ASSY
412-030-326-103	PANEL ASSY
AAL-061-301-009	DUCT ASSY
AB205-030-856-121	ELEVATOR
D205-633-017	HELI-ACCESS-STEP - LOW GEAR, FITS LH OR RH
D205-634-141	REPLACEMENT SKIDTUBE WITH RUN-ON LANDING WEARPLATES FITS LH OR RH
E350-1011-041	MX-10 DUMMY BRACKET ASSY
H205-031-257-067	PANEL, FLOOR
SP-7109-12	CARGO HOOK
SP-7109-62S	CARGO HOOK

ROTOR & DRIVE TRAIN

PART NUMBER	PART DESCRIPTION
204-011-111-003	BEARING
204-011-121-009G	GRIP ASSY
204-011-402-017	INNER RING
204-011-402-131	INNER RING ASSY
204-040-102-017	PINION ASSY
204-040-324-005	SHAFT
204-040-334-009	COVER ASSY
204-040-397-001	SPIDER ASSY
204-040-785-003	SPIDER
204-040-786-001	PLATE SET

PART NUMBER	PART DESCRIPTION
205-011-711-101	GRIP ASSY
205-040-263-105	INPUT QUILL ASSEMBLY
212-010-300-001FM	STABILIZER BAR ASSEMBLY
212-010-701-035	T/R HUB ASSY
212-040-053-009	CASE ASSY
212-040-054-007	CASE ASSY
212-040-151-009	GEAR ASSY
212-040-201-001	GEAR
212-040-202-003	PINION
212-040-203-001	SLEEVE, ASSY OF
212-040-452-001	SLEEVE, ASSY OF
212-040-686-001	DRIVESHAFT ASSY
214-040-118-001	BEARING
214-040-125-101	BEARING
406-040-030-107	BRG, BALL-TRI
406-040-400-121	GEARBOX ASSY
406-040-400-121FM	T/R GEARBOX
406-040-406-101	CASE ASSY
406-040-406-109	CASE ASSY
406-040-406-113FM	CASE ASSY
406-040-416-101	SHAFT
406-040-500-131FM	FREEWHEELING AS
406-310-402-103	BEARING
407-012-101-107	HUB ASSY
407-040-038-123A	MAST ASSY
407-040-325-107	SHAFT ASSY
407-040-330-107	SHAFT ASSY
407-310-102-101	BEARING
412-010-402-113	SWASHPLATE
412-010-402-115	SWPL&SPRT ASSY
412-040-005-103FM	MAIN DRIVESHAFT
412-040-230-101	GEAR
412-040-525-101	ROTOR
412-340-125-101	BEARING - BALL, MAST, MRGB
4AA-010-106-101	PMA BEARING
76351-09053-042	GEAR, HELICAL-HYDRAULIC

ENGINE & FUEL SYSTEM

PART NUMBER	PART DESCRIPTION
1-101-040-01	EXIT GUIDE VANE SET, ASSY OF
1076T-1	ENGINE INLET AIR FILTER SYSTEM
204-060-210-103	SCREEN ASSEMBLY
205-060-605-001	L/H FUEL CELL
205-061-632-002	R/H FUEL CELL
205-072-277-003	VALVE
209-072-433-005	BLEED AIR VALVE
209-072-433-007	VALVE ASSEMBLY
209-072-433-101	VALVE ASSEMBLY
209-072-433-105	VALVE
212-060-722-001	MOUNT ASSY OF
212-061-201-011	EJECTOR ASSY
212-061-201-012	EJECTOR ASSY
212-061-202-010	DUCT
212-061-207-289	WEB ASSY
214-073-903-001	VALVE ASSY
300289-1	TUBE ASSY, METAL
3106186-01	HSGPTSHY
3244706-7	TORQUE CONTROL UNIT
412-060-603-103	FUEL CELL ASSY
412-361-635-101	FUEL CELL
412-361-639-102	FUEL CELL
D205-708-011	ADJUSTABLE ENGINE MODIFICATION
PT6-3/3B ADAPTER SET	P & W NOZZLE SET (QTY 14) W/O SHEATHS
PT6T-3B NOZZLE KIT	NOZZLE KIT

AVIONICS & INSTRUMENTS

PART NUMBER	PART DESCRIPTION
145974-01-03	VERT GYRO
204-072-129-101	DUAL TACH IND
212-070-160-005	INDICATOR
212-070-160-113	INDICATOR
212-070-160-123FM	INDICATOR, DUAL TORQUE
212-070-160-131FM	DUAL TORQUE INDICATOR

PART NUMBER	PART DESCRIPTION
212-075-420-003	ITT GAUGE
214-075-244-001	RATE GYRO
2192-30-111100	NAV COMPUTER UNIT, UNS-1F
4033089-901	COMPUTER, FLT DI
412-375-001-105	INDICATOR
412-375-004-109	SENSOR ASSY
412-375-007-113	TRIPLE TRQ, IND
501-1113-01	VERTICAL GYRO
7000839-904	INDICATOR
7011672-781	GENERATOR, SYMBOL
7021450-401	ANTENNA - RECEIVER / TRANSMITTER WU-440
76228310	INDICATOR, FUEL GAGE
8DJ67FCA	DUAL TACH
96774-18-1814	TORQUE TRANSMITTER
K10-00205-00	GARMIN GRA 55 KIT (2-S67-2002 ANTENNAS, MOUNTING RACK, GRA 55 UNIT AND GI 205 CONNECTOR)

HYDRAULICS & FLIGHT CONTROLS

PART NUMBER	PART DESCRIPTION
205-076-031-003	HYDRAULIC SERVO
205-076-036-105	CYLINDER ASSY
205-076-036-107	HYDRAULIC SERVO
205-076-038-007	CYLINDER ASSY
205-DUAL KIT	DUAL HYDRAULIC KIT
206-076-062-127	SERVO ACTUATOR
212-001-303-005	SUPPORT ASSY
212-076-004-103	ACTUATOR-HYD
212-076-006-005	FILTER
212-076-006-5	FILTER
32-00117-0044-1	KIT, PUMP UPGRADE
4012373-905	LINEAR ACTUATOR
412-010-406-117FM	LINK ASSEMBLY
7001483-901	CONTROL ROD ASSY
7001484-901	CONTROL ROD ASSEMBLY
979142-3-1	VALVE ASSEMBLY
PV3-044-8	HYDRAULIC PUMP

PART NUMBER	PART DESCRIPTION
SYLC9548-1	ACTUATOR, ELMCH, LINEAR

ELECTRICAL & LIGHTING

PART NUMBER	PART DESCRIPTION
15-0149-1	LIGHT, COCKPIT, AIRCRAFT
200SGL111Q	STARTER GENERATOR
204-070-540-003	SUPPRESSOR
212-073-927-001	MOTOR
212-075-406-001	PANEL ASSY
G8385-1	LIGHT ASSEMBLY
HARNESS, 205A-1 A/F	HARNESS, COMPLETE 205A-1 A/F ELECTRICAL
HARNESS, 212 A/F	HARNESS, COMPLETE 212 A/F ELECTRICAL

SAFETY & EMERGENCY EQUIPMENT

PART NUMBER	PART DESCRIPTION
412-706-004-163	EMERGENCY FLOAT
614.5702	MID FLOAT W/LIFERAFT ASSEMBLY RH
D412-706-011	FUEL PURGE CANISTER

For Availability & Pricing, please contact partsales@eaglecopters.com