EAGLE COPTERS LTD. · CALGARY, CANADA

EPCS
EAGLE PART & COMPONENT SOLUTIONS

ROTORCRAFT PARTS INVENTORY

HIGH-DEMAND PARTS AVAILABLE NOW

Engine, rotor, drive train, avionics and hydraulic components ready to ship.

PART DESCRIPTION	PART NUMBER
Power Section (PT6T-3)	3017600
Main Rotor Hub Assy	407-010-100-123FM
Fuel Control Unit	3244721-11-10
Power Turbine Governor	3244885-4

PART DESCRIPTION	PART NUMBER
Mast Assembly	204-040-366-021FM
Hydraulic Servo	212-076-005-101
IIDS	76450-01098-108
Starter Generator	30E20-61A

For Availability & Pricing, please contact partsales@eaglecopters.com

EAGLE COPTERS LTD. · CALGARY, CANADA

EPCS
EAGLE PART & COMPONENT SOLUTIONS

HIGH-DEMAND PARTS LIST

FEATURED COMPONENTS

PART DESCRIPTION	PART NUMBER	CATEGORY
Power Section (PT6T-3/3B/3BE/3BF)	3017600	Engine
Main Rotor Hub Assy	407-010-100-123FM	Rotor
IIDS	76450-01098-108	Avionics
Fuel Control Unit	3244721-11-10	Engine
Pump and Metering Valve Assy	0292862650	Engine
Power Turbine Governor	3244885-4	Engine
RDAU	76450-01098-112	Avionics
Mast Assembly	204-040-366-021FM	Drive train
MFDAU	2231230-10-A-1	Avionics
Replacement Engine Mounts	D205-770-011	Engine install
Hydraulic Servo	212-076-005-101	Hydraulics
Scissors and Sleeve Assy	204-011-401-021	Rotor
Driveshaft, Input	412-040-005-103	Drive train
Collective Bell Crank Assembly	D212-725-1-901	Flight controls
Damper Bearing Assy	412-010-190-105	Rotor
EFIS Display	7003110-902	Avionics
Starter Generator	30E20-61A	Electrical
FDR/CVR	D51615-102	Avionics

For Availability & Pricing, please contact partsales@eaglecopters.com

AVIONICS & INSTRUMENTS

PART NUMBER	PART DESCRIPTION
011-00550-10	GARMIN 530
011-01060-00	DISPLAY
011-03300-00	GTX 335 TRANSPONDER
064-1023-00	VHF COMM XCVR
064-1054-30	TRANSCEIVER, KY-196A
0789-03-307-3	DUAL TACH INDICATOR
091258-1-10	TDFM 136A VHF FM RADIO
103-0503-03-01	RC ALLEN DIGITAL HEADING INDICATOR
110-338	ROD ANTENNA, AR
111302-5	IND, HSI
111303-4	IND, ADI
124.043	IND-HYDR
15035-01102	ALTIMETER 2" HG SCALE
15175	VXP ACQUISTION
1616-050-03A	SKY CONNECT TRANSCEIVER
204-072-129-005	INDICATOR-TACH
204-072-129-101	DUAL TACH IND
204-075-705-073	CAUTION PANEL
209-070-262-009	INDICATOR
209-070-262-101	INDICATOR ENG OIL TEMP
209-070-264-003	INDICATOR
209-075-326-005	RPM LIMIT DETECTOR
212-070-116-009	INDICATOR
212-070-122-009	INDICATOR
212-070-160-007	IND, TORQUE
212-070-160-101	TORQUE INDICATOR
212-070-160-129FM	DUAL TORQUE
212-070-239-001	RATE OF CLIMB
212-070-242-003	INDICATOR
212-075-037-101	INDICATOR
212-075-067-109	INDICATOR-ITT
212-075-562-003	INDICATOR
217-01161	TORQUE INDICATOR
222-375-077-119	TRANSMITTER

PART NUMBER	PART DESCRIPTION
2231230-10-A-1	MFDAU
2593996-333	TARSYN GYRO
2594484	XMTR, FLUX VALVE
32005-037	GENERATOR, TACH
3567758-6503	OIL PRESSURE TRANSMITTER
380-005	PANEL, AUDIO
393004-051	INDICATOR
393008-040	INDICATOR, LIQUID QUANTITY
393008-046	INDICATOR
393008-047	IND (WHITE)
4020936-903	GYRO
407-375-001-105	IND-MGT
50579	TRANSMITTER, HYDRAULIC PRESS
5550-8340N5L	TURN & BANK INDICATOR
622-6520-007	COMM CONTROL PANEL
622-6521-015	NAVIGATION CONTROL
622-6522-007	ADF CONTROL PANEL
622-6524-003	IND-DME
622-9210-007	TDR-94D XPNDR
64200-003	DUAL TACHOMETER
65100-057	TORQUE INDICATOR
7000839-904	INDICATOR
7003110-902	EFIS DISPLAY
76302-07800-108	IBF MONITOR/DISPLAY
76450-01098-108	IIDS
76450-01098-110	IIDS
76450-01098-112	RDAU
805-10800-001	TRC497 TRANSMITTER/RECEIVER COMPUTER
8DJ131LAV1	TRIPLE TACH INDICATOR
CB-2100-T6-D	COMPASS
D212-722-011	AVIONICS RISER CONSOLE
D51615-102	FDR/CVR
D60350MK241105	AIRDATA COMP
G13116	DIGITAL CONTROL PANEL
IPT-20RT1-1000-80G	PRESSURE TRANSDUCER, TORQUE
JA94-044A	AUDIO CONTROLLER DUAL JUPITER AVIONICS

ENGINE & FUEL SYSTEM

PART NUMBER	PART DESCRIPTION
025277-300-07	FUEL PUMP
0292862650	PUMP AND METERING VALVE ASSY, ADJUSTED
0401273020	BEARING
0401277050	ENG.MT OUTBD
1-130-730-02	MANIFOLD
1-300-405-01	NOZZLE
10-381550-4	EXCITER
10544E	HEATER OIL TO FUEL
204-060-302-013	TAILPIPE ASSY
204-060-729-001	ARM
204-060-762-103	ACTUATOR
204-060-787-009	CAMBOX ASSY
204-060-815-071	SPACER
204-060-816-031	RING
205-060-139-001	FITTING
205-060-439-001	FITTING
205-060-612-003	VALVE
205-060-721-001	BELLCRANK ASSY
205-061-632-002	R/H FUEL CELL
205-061-633-009	PROBE
205-061-633-011	PROBE
205-061-633-013	PROBE
209-062-214-001	ACTUATOR
209-062-501-001	OIL COOLER
209-062-501-002	OIL COOLER
209-062-501-005	OIL COOLER
209-062-761-001	SOLENOID
212-061-107-003	TRI-POD ASSY OF
212-061-108-003	BI-POD ASSY
300286-1	CROSSOVER
300288-501	CROSSOVER ASSEM
300289-7	CROSSOVER ASSY
3017600	POWER SECTION (PT6T-3/3B/3BE/3BF)
3244706-6	TORQUE CONTROL UNIT

PART NUMBER	PART DESCRIPTION
3244708-1	FUEL PRESSURE REGULATOR
3244721-11-10	FUEL CONTROL UNIT
3244885-4	GOVERNOR, POWER TURBINE
391046-200	TANK UNIT
540-1407-4	BLEED VALVE, ADJUSTABLE
AV16B1667D	VALVE FUEL SHUTOFF
D205-770-011	REPLACEMENT ENGINE MOUNTS
PT6-3/3B ADAPTER SET-S	P & W NOZZLE SET (QTY 14) W/ SHEATHS

ROTOR & DRIVE TRAIN

PART NUMBER	PART DESCRIPTION
204-010-937-009	DAMPER
204-011-401-021	SCISSORS AND SLEEVE ASSY
204-040-190-101	RACE
204-040-334-009	COVER ASSY
204-040-366-021	MAST ASSY
204-040-366-021FM	MAST ASSEMBLY
204-040-399-007	SLEEVE ASSY
204-040-600-011	HANGER ASSEMBLY
204-040-812-003	ADAPTER
205-040-242-001	BEARING
205-040-246-003	BEARING
205-040-249-001	BEARING
205-040-249-003	BEARING
209-011-710-005	TUBE-ASSY OF
209-040-177-101	FLANGE
212-010-300-001	STAB BAR
212-010-701-139	HUB ASSY
212-040-003-007	42 DEG GEARBOX
212-040-005-103	DRIVESHAFT
212-040-144-103	BEARING
212-040-149-001	GEAR ASSY
212-040-151-009	GEAR ASSY
212-040-206-101	ADAPTER
212-040-600-009	T/R HANGER COUPLINGS
35-79501-1145-2	SHAFT

PART NUMBER	PART DESCRIPTION
406-040-036-107	BRG, BALL-UPPER
406-040-500-143FM	FREEWHEEL ASSEMBLY
406-310-405-105	BEARING
407-010-100-123FM	MAIN ROTOR HUB ASSY
407-310-101-101	BEARING
407-310-101-105	BEARING
407-310-102-103	BEARING
407-310-203-101	MOUNT, CORNER
407-312-100-101	BEARING
407-340-032-101	BEARING
407-340-339-107	BEARING
412-010-190-105	DAMPER BRG ASSY
412-010-422-105	PIN
412-040-005-103	DRIVESHAFT, INPUT
412-040-102-103	LINER
412-040-123-101	QUILL ASSY
53418C1950M	COUPLING
76103-05003-042	PITCH CHANGE
76104-08040-042	STAT SCISSOR
76107-08100-043	BIFILAR ASSY
76361-04008-103	COUPLING
SB5064-102	BEARING

HYDRAULICS & FLIGHT CONTROLS

PART NUMBER	PART DESCRIPTION
204-076-055-001	VALVE
205-001-902-005FM	BELLCRANK ASSY
205-001-908-001	IDLER ASSY
205-001-908-005	IDLER ASSY
205-001-914-103	HORN ASSY
205-072-277-009	VALVE
205-076-030-001	HYDRAULIC SERVO
212-001-712-101	BELLCRANK ASSY
212-076-004-003	T/R SERVO
212-076-004-101	ACTUATOR-HYD
212-076-005-007	HYDRAULIC SERVO

PART NUMBER	PART DESCRIPTION
212-076-005-101	HYDRAULIC SERVO
212-076-006-007	INTEGRATED VALVE & FILTER
212-076-006-105	VALVE AND FILTER ASSY
212-076-011-001	HYDRAULIC PUMP
212-076-015-001	VALVE ASSY
212-310-701-105	LINK ASSY
70-038F400-180	HOSE ASSY
76106-08050-043	RESERVOIR ASSY
D212-725-1-901	COLLECTIVE BELL CRANK ASSEMBLY
L109CBM	ACTUATOR

ELECTRICAL & LIGHTING

PART NUMBER	PART DESCRIPTION
0789-17-002-1	4962-J8A/J8 HARNESS ASSEMBLY
0789-17-003-1	4962-J196 HARNESS ASSEMBLY
0789-17-012-1	1P1 ENGINE HARNESS ASSEMBLY
200SGL144Q	DC STARTER GENERATOR
209-075-228-001	REGULATOR
209-075-325-045	PANEL
23046-020	STARTER GENERATOR
30E20-61A	STARTER GENERATOR
384178-091	SWITCH
384178-103	SWITCH
42D218	PRESSURE SWITCH
44410-2-24	LIGHT ASSEMBLY
51509-002R	CONTROL UNIT
51530-006B	GENERATOR CONTROL UNIT
592840-1	GNDING MODULE
AA21-400	CABIN PA SYSTEM WHITE LIGHT
ASH584-5	INVERTER
G-6250-4	SEARCHLIGHT
G5400-6	LANDING LIGHT
HARNESS, 212S A/F	HARNESS, COMPLETE 212S ELECTRICAL
MS25358-7	DOME LIGHT ASSY
PS304-1	INVERTER

AIRFRAME & INTERIOR

PART NUMBER	PART DESCRIPTION
19131-1537M	CLAMP
2024-T3.125 PER AMS-QQ-A-250/4	ALUMINUM SHEET
204-031-920-003	DAMPER
205-031-282-057	L/H FWD FUEL CELL BELLY PANEL
205-031-423-042	FRAME
205-031-818-101	FITTING
205-060-807-083	COWL ASSEMBLY
205-060-807-084	COWL ASSEMBLY
205-060-826-011	ENGINE COWL LOWER L/H
205-070-333-004	BRACKET
205-070-492-007	DUCT ASSY OF
210-044-01	E-47B LOAD CELL ASSEMBLY
212-030-437-007	CAP
412-030-100-121	TRACK ASSY
76206-01001-112	WINDSHIELD
76302-07800-109	STATIC BASKET
ASI-6404	SEATS FUEL CELL
ASI-6408	SEATS STANDARD
D205-765-011	DRIVE SHAFT TUNNEL KIT
D412-709-013	ESCAPE PANEL PUSH-OUT REPLACEMENT WINDOW, CLEAR - FITS LH OR RH

SAFETY & EMERGENCY EQUIPMENT

PART NUMBER	PART DESCRIPTION
30-207-23	DETECTOR
30-231-9	SMOKE DETECTOR
3001-38-450/170C3.6M	FIRE/OVERHEAT DETECTOR
648.7501	BELL 412 LIFERAFT RESERVOIR ASSEMBLY
D24677-103	L/H NOSE FLOAT
DK120	BEACON UNDERWATER
DK140	BEACON, ACOUSTIC
V212-0525M	EMERGENCY NOSE SURVIVAL KIT

For Availability & Pricing, please contact partsales@eaglecopters.com